

Content

| | |
|--|----|
| Content | 1 |
| Introduction | 3 |
| Version History | 3 |
| Hardware to Library Cross-Reference | 4 |
| FBESysEncoder.lib | 5 |
| Hardware Reference | 5 |
| SysEncoder_Clear | 5 |
| SysEncoder_Control | 6 |
| SysEncoder_RegisterCB | 6 |
| SysEncoder_Init | 7 |
| SysEncoder_Preset | 7 |
| SysEncoder_Read16Bit | 8 |
| SysEncoder_Read32Bit | 8 |
| SysEncoder_Start | 8 |
| SysEncoder_Stop | 8 |
| FBESysFile.lib | 9 |
| Hardware Reference | 9 |
| SysDirSet | 9 |
| SysFileClose | 9 |
| SysFileCopy | 10 |
| SysFileDelete | 10 |
| SysFileEOF | 10 |
| SysFileGetPos | 10 |
| SysFileGetSize | 11 |
| SysFileGetSized | 11 |
| SysFileOpen | 11 |
| SysFileRead | 11 |
| SysFileSetPos | 12 |
| SysFileWrite | 12 |
| FBESysInterrupt.lib | 13 |
| Hardware Reference | 13 |
| SysInterrupt_ClrRequest | 13 |
| SysInterrupt_DeleteService | 13 |
| SysInterrupt_Disable | 14 |
| SysInterrupt_Enable | 14 |
| SysInterrupt_RegService | 15 |
| SysInterrupt_SetRequest | 15 |
| FBESysPWM.lib | 16 |
| Hardware Reference | 16 |
| SysPwm_Close | 16 |
| SysPwm_Open | 17 |
| SysPwm_SetDuty | 17 |
| SysPwm_Start | 18 |
| SysPwm_Stop | 18 |
| FBESysSmPos.lib | 19 |
| Hardware Reference | 20 |
| SmPos_ChangeRampPara | 20 |
| SmPos_CloseAxis | 21 |
| SmPos_DefHome | 21 |
| SmPos_EncAssign | 21 |
| SmPos_EncRelease | 21 |
| SmPos_EncStopUse | 21 |
| SmPos_EncUse | 21 |
| SmPos_GetActualPos | 21 |
| SmPos_GetActualSettings | 22 |
| SmPos_GetDemandPos | 22 |
| SmPos_GetDemandVelocity | 22 |
| SmPos_GetSlip | 22 |
| SmPos_IsAxisActive | 22 |
| SmPos_IsAxisMoving | 23 |
| SmPos_IsPositionReached | 23 |
| SmPos_OpenAxis | 23 |
| SmPos_SetActualPos | 24 |
| SmPos_SetActualToHome | 24 |
| SmPos_SetDemandPos | 24 |
| SmPos_SetOffset | 25 |
| SmPos_SetVelocity | 25 |
| SmPos_StartMotion | 25 |
| SmPos_StopMotion | 25 |
| SmPos_SyncAxis | 26 |
| SmPos_UnSyncAxis | 26 |
| FBESysUtil.lib | 27 |
| SysUtil_GetFV | 27 |
| SysUtil_GetSysTime | 27 |
| SysUtil_GetTargetId | 27 |
| SysUtil_LedSet | 28 |
| SysUtil_GetTaskInfo | 28 |
| SysUtil_GetSerNo | 28 |
| FBESysSerial.lib | 29 |
| Hardware Reference | 29 |
| SysCom_Clear | 30 |
| SysCom_Close | 30 |
| SysCom_GetRxBufNum | 30 |
| SysCom_GetStatus | 30 |
| SysCom_Init | 31 |
| SysCom_IsRxReady | 31 |
| SysCom_Read | 32 |
| SysCom_ReadBlock | 32 |
| SysCom_ReadString | 32 |
| SysCom_ReOpen | 33 |
| SysCom_Write | 33 |
| SysCom_WriteString | 33 |
| SysCom_WriteBlock | 34 |
| FBESysUSB.lib | 34 |
| Hardware Reference | 34 |
| SysUSB_Clear | 34 |
| SysUSB_Close | 34 |
| SysUSB_IsConnected | 35 |
| SysUSB_IsRxReady | 35 |
| SysUSB_Open | 35 |
| SysUSB_RxBlock | 36 |
| SysUSB_RxByte | 36 |
| SysUSB_RxString | 37 |
| SysUSB_TxBlock | 38 |
| SysUSB_TxByte | 38 |
| SysUSB_TxString | 39 |
| FBESysCAN.lib | 40 |
| Hardware Reference | 40 |
| SysCAN_InitBasicCan | 40 |
| SysCAN_IsRxMsg | 41 |

| | | | |
|----------------------------------|-----------|---------------------------------|-----------|
| SysCAN_Receive..... | 41 | SysNet_HttpSetDir..... | 56 |
| SysCAN_RxMsg | 41 | SysNet_HttpRegCgiFunction | 56 |
| SysCAN_Send | 42 | FBESYSMemory.lib | 58 |
| SysCAN_TxMsg | 42 | SysMem_EepromRd..... | 58 |
| SysCAN_CanNodeGetStatus | 43 | SysMem_EepromWr..... | 58 |
| SysCAN_CanNodeRecover | 43 | SysMem_NVBlockEnable | 58 |
| SysCAN_CanNodeRecover | 43 | SysMem_NVBlockDisable | 59 |
| SysCAN29Bit_IsRxMsg | 44 | SysMem_SaveRetainCmd..... | 59 |
| SysCAN29Bit_Send..... | 44 | FBESysTime.lib | 60 |
| SysCAN29Bit_Receive | 44 | SysTime_GetTime | 60 |
| SYSCIA405.lib..... | 44 | SysTime_GetDate..... | 60 |
| Hardware Reference | 45 | SysTime_GetDateandTime | 60 |
| SysCiA405_Get_Kernel_State..... | 46 | SysTime_SetDate | 60 |
| SysCiA405_Get_Local_Node_Id..... | 46 | SysTime_SetDateandTime | 61 |
| SysCiA405_Get_State | 47 | SysTime_SetTIME | 61 |
| SysCiA405_Is_Any_EMCY | 47 | FBESyslo.lib..... | 62 |
| SysCiA405_NMT | 48 | Syslo_RdAllDigitalIn | 62 |
| SysCiA405_Recv_EMCY | 48 | Syslo_WrAllDigitalOut | 62 |
| SysCiA405_Recv_EMCY_Dev..... | 50 | Syslo_ResetDigitalOut | 62 |
| SysCiA405_SDO_READ4..... | 50 | Syslo_SetDigitalOut | 63 |
| SysCiA405_SDO_WRITE4 | 51 | Syslo_GetDigitalIn | 63 |
| FBESysTask.lib..... | 52 | Syslo_GetErrStatus | 63 |
| SysTask_GetTimeCycle..... | 52 | Syslo_SetWdtMode | 64 |
| SysTask_GetProcessTime..... | 52 | Syslo_WrAllAnalogOut | 64 |
| FBESysNet.lib | 53 | Syslo_WrAnalogOut | 64 |
| Hardware Reference | 53 | FBESysJ1939.lib..... | 65 |
| SysNet_EmailCreate | 54 | Hardware Reference | 65 |
| SysNet_EmailSend | 54 | J1939_InitCan | 65 |
| SysNet_EmailSetFooter | 54 | J1939_IsRxMsg | 65 |
| SysNet_EmailSetHeader | 55 | J1939_RxMsg | 66 |
| SysNet_EmailSetRecipient | 55 | J1939_TxMsg | 66 |
| SysNet_EmailSetSubject | 55 | | |
| SysNet_EmailTextClear | 55 | | |
| SysNet_EmailWrite | 56 | | |

Introduction

In order to support the powerful PLC modules there are library extensions for the CoDeSys development environment. Any libraries are internal, that means they are implemented in the PLC runtime system. Others are external IEC-Code libraries.

The following libraries are available:

| Library name | available | Description | Type |
|----------------------|-----------|--|------|
| FBESysEncoder.lib | 12.2010 | Support of incremental encoders | RT |
| FBESysFile.lib | 12.2010 | Support of file system | RT |
| FBESysInterrupt.lib | 12.2010 | Implementation of Interrupt service routines | RT |
| FBESysPWM.lib | 12.2010 | Support of pulse wide modulation | RT |
| FBESysSmPos.lib | 12.2010 | Support of stepper motor | RT |
| FBESysUtil.lib | 12.2010 | Sundry helpful functions | RT |
| FBESysCAN.lib | 12.2010 | Functions for basic CAN support | RT |
| FBESysCiA405.lib | 12.2010 | Functions for CiA405 handling | RT |
| FBESysCiA405_StdBus0 | 12.2010 | Same as FBESysCiA405 but only for standard bus interface 0 | RT |
| FBESysIO.lib | 12.2010 | Functions for fast IO handling | RT |
| FBESysMemory.lib | 12.2010 | Support of EEPROM handling | RT |
| FBESysNet.lib | 03.2011 | Support of hipecs webserver | RT |
| FBESysSerial.lib | 12.2010 | Support of serial interfaces | RT |
| FBESysTask.lib | 12.2010 | Support of Task handling | RT |
| FBESysTime.lib | 12.2010 | RTC handling | RT |
| FBESysUSB.lib | 12.2010 | Support of USB interfaces | RT |
| FBESysJ1939.lib | 07.2013 | Support of J1939 message format for basic CAN | RT |

RT: included in PLC Runtime system

IEC: external IEC-Code library

Version History

| Library Version | date | Description |
|-----------------|------------|---|
| 1.00 R3 | 10.11.2011 | first release with hipecs serial production start |
| 1.00 R4 | 15.01.2014 | added J1939 Lib and several other functions |

Hardware to Library Cross-Reference

Not all libraries work with each hipecs Module because they have different hardware units for application. This reference shows the libraries, which can be used with each hipecs.

| Library name | hipecs PLC 1010 | hipecs PLC 1020 | hipecs PLC 1030 | hipecs PLC 1210 | hipecs PLC 1220 | hipecs PLC 1230 | | | |
|----------------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|--|--|--|
| FBESysEncoder.lib | X | X | X | X | X | X | | | |
| FBESysFile.lib | X | X | X | X | X | X | | | |
| FBESysInterrupt.lib | X | X | X | X | X | X | | | |
| FBESysPWM.lib | X | X | X | X | X | X | | | |
| FBESysSmPos.lib | X | X | X | X | X | X | | | |
| FBESysUtil.lib | X | X | X | X | X | X | | | |
| FBESysCAN.lib | X | X | X | X | X | X | | | |
| FBESysCiA405.lib | X | X | X | X | X | X | | | |
| FBESysCiA405_StdBus0 | X | X | X | X | X | X | | | |
| FBESysIO.lib | X | X | X | X | X | X | | | |
| FBESysMemory.lib | X | X | X | X | X | X | | | |
| FBESysNet.lib | | | X | | X | X | | | |
| FBESysSerial.lib | X | X | X | X | X | X | | | |
| FBESysTask.lib | X | X | X | X | X | X | | | |
| FBESysTime.lib | X | X | X | X | X | X | | | |
| FBESysUSB.lib | | | X | | | X | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

FBESysEncoder.lib

| Functions | Description |
|-----------------------|---|
| SysEncoder_Clear | This function clears the encoder by resetting its value. New value will be 0. |
| SysEncoder_Control | This function sets, reads, clears or presets the encoder value at once. Also enabling or disabling (start/stop) of encoder counting is possible with this function. |
| SysEncoder_Init | Initialize an encoder interface |
| SysEncoder_Preset | Set new encoder value |
| SysEncoder_Read16Bit | Read encoder value |
| SysEncoder_Read32Bit | Read encoder value |
| SysEncoder_Start | Start encoder |
| SysEncoder_Stop | Stops encoder |
| SysEncoder_RegisterCB | Register Call Back: Define an IRQ that shall be called if an over-/underflow of the encoder occurs. |

Data types defined for encoder library

```
TYPE type_ENCODER : (
    ENCODER0:= 0,
    ENCODER1:= 1,
    ENCODER2:= 2,
    ENCODER3:= 3
);
```

END_TYPE

Hardware Reference

hipecs PLC1000

| Number of PWM channels | 4 | | | |
|----------------------------|----------|----------|----------|----------|
| Channel number | 0 | 1 | 2 | 3 |
| Channel name | ENCODER0 | ENCODER1 | ENCODER2 | ENCODER3 |
| Input frequency max. (kHz) | 100 | 100 | 100 | 100 |
| Input track A | DIN0.0 | DIN0.2 | DIN0.4 | DIN0.6 |
| Input track B | DIN0.1 | DIN0.3 | DIN0.5 | DIN0.7 |

hipecs PLC1000 offers 3 channels for track A/B encoder and 1 event counter. These channels are special functions on the digital input group 0.

SysEncoder_Clear

| name | SysEncoder_Clear | | | type | Function |
|---------------|---|----------------|---|------|----------|
| return value | type | BOOL | | | |
| | | TRUE | Function ended successfully. | | |
| | | FALSE | Function skipped. | | |
| input value 1 | name | Encoder | | | |
| | type | type_ENCODER | Selects the hardware related encoder channel by name. | | |
| | value | [Channel name] | See hardware reference table for valid channel name | | |
| description | This function clears the encoder by resetting its value. New value will be 0. | | | | |

SysEncoder_Control

| <i>name</i> | SysEncoder_Control | | | <i>type</i> | <i>Function</i> |
|----------------------|---|--------------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | DINT | | | |
| | | [0 .. FFFFFFFF] | <i>Actual encoder Value.</i> | | |
| <i>input value 1</i> | <i>name</i> | Encoder | | | |
| | <i>type</i> | type_ENCODER | Selects the hardware related encoder channel by name | | |
| | <i>value</i> | {Channel name} | See hardware reference table channel name | | |
| <i>input value 2</i> | <i>name</i> | Enable | | | |
| | <i>type</i> | BOOL | Enables / Disables encoder for counting. | | |
| | <i>value</i> | TRUE | Encoder will be enabled. | | |
| | | FALSE | Encoder will be disabled. | | |
| <i>input value 3</i> | <i>name</i> | Clear | | | |
| | <i>type</i> | BOOL | Encoder Clear Flag. | | |
| | <i>value</i> | TRUE | Encoder will be cleared. New Value 0. | | |
| | | FALSE | Encoder value will be unchanged. | | |
| <i>input value 4</i> | <i>name</i> | Preset | | | |
| | <i>type</i> | BOOL | Encoder preset flag. | | |
| | <i>value</i> | TRUE | Encoder value will be set to preset value. | | |
| | | FALSE | Encoder value will be unchanged. | | |
| <i>input value 5</i> | <i>name</i> | PresetValue | | | |
| | <i>type</i> | DINT | New encoder value | | |
| | <i>value</i> | [0 .. FFFFFFFF] | | | |
| <i>description</i> | This function sets, reads, clears or presets the encoder value at once. Also enabling or disabling (start/stop) of encoder counting is possible with this function. | | | | |

SysEncoder_RegisterCB

| <i>name</i> | SysEncoder_RegisterCB | | | <i>type</i> | <i>Function</i> |
|----------------------|--|----------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| | | FALSE | <i>Function skipped. Faulty parameters</i> | | |
| <i>input value 1</i> | <i>name</i> | Encoder | | | |
| | <i>type</i> | type_ENCODER | Selects the hardware related encoder channel by name | | |
| | <i>value</i> | {Channel name} | See hardware reference table channel name | | |
| <i>input value 2</i> | <i>name</i> | nPOU_ID | | | |
| | <i>type</i> | INT | Index of interrupt service routine that shall be called at over- or underflow | | |
| | <i>value</i> | INDEXOF(XXX) | By using the CODESYS operator "INDEXOF(My_POU)" you can assign the POU ID | | |
| <i>description</i> | By using this function, you can call an interrupt service routine if an overflow or underflow of the encoder value occurs. | | | | |

SysEncoder_Init

| <i>name</i> | SysEncoder_Init | | | <i>type</i> | <i>Function</i> |
|----------------------|--|------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | <i>value</i> | FALSE | <i>Function skipped.</i> | | |
| | <i>name</i> | Encoder | | | |
| | <i>type</i> | type_ENCODER | Selects the hardware related encoder channel by name | | |
| <i>input value 2</i> | <i>value</i> | {Channel name} | See hardware reference table channel name | | |
| | <i>name</i> | Mode | | | |
| | <i>type</i> | USINT | Operation mode | | |
| | <i>value</i> | 0 | Encoder channel close/release. | | |
| | | 1 | Track A/B encoder mode. | | |
| | | 2 | Event counter mode. | | |
| <i>input value 3</i> | <i>name</i> | HighRes | | | |
| | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | Activates High Resolution Mode | | |
| | | FALSE | Low Res Mode | | |
| <i>input value 4</i> | <i>name</i> | InvertDir | | | |
| | <i>type</i> | BOOL | Invertes counting direction | | |
| | <i>value</i> | TRUE | | | |
| | | FALSE | | | |
| <i>input value 5</i> | <i>name</i> | Start | | | |
| | <i>type</i> | BOOL | Starts encoder function | | |
| | <i>value</i> | TRUE | counting starts immediately | | |
| | | FALSE | encoder is initialized but doesn't start counting yet | | |
| <i>description</i> | Function must be called once to register encoder in the OS. The inputs for CODESYS are NOT available while encoders are initialized. | | | | |

SysEncoder_Preset

| <i>name</i> | SysEncoder_Preset | | | <i>type</i> | <i>Function</i> |
|----------------------|--|--------------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | <i>value</i> | FALSE | <i>Function skipped. Channel number is out of range.</i> | | |
| | <i>name</i> | Encoder | | | |
| | <i>type</i> | type_ENCODER | Selects the hardware related encoder channel by name | | |
| <i>input value 2</i> | <i>value</i> | {Channel name} | See hardware reference table channel name | | |
| | <i>name</i> | PresetValue | | | |
| | <i>type</i> | DINT | New encoder value | | |
| | <i>value</i> | [0 .. FFFFFFFF] | | | |
| <i>description</i> | Sets a new value for the encoder channel | | | | |

SysEncoder_Read16Bit

| <i>name</i> | SysEncoder_Read16Bit | | | <i>type</i> | <i>Function</i> |
|----------------------|-------------------------------------|----------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | INT | | | |
| | <i>value</i> | [0 .. FFFF] | <i>Actual encoder value</i> | | |
| <i>input value 1</i> | <i>name</i> | Encoder | | | |
| | <i>type</i> | type_ENCODER | Selects the hardware related encoder channel by name | | |
| | <i>value</i> | {Channel name} | See <i>hardware reference table channel name</i> | | |
| <i>description</i> | read encoder value in 16 bit format | | | | |

SysEncoder_Read32Bit

| <i>name</i> | SysEncoder_Read32Bit | | | <i>type</i> | <i>Function</i> |
|----------------------|-------------------------------|-----------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | DINT | | | |
| | <i>value</i> | [0 .. FFFFFFFF] | <i>Actual encoder value</i> | | |
| <i>input value 1</i> | <i>name</i> | Encoder | | | |
| | <i>type</i> | type_ENCODER | Selects the hardware related encoder channel by name | | |
| | <i>value</i> | {Channel name} | See <i>hardware reference table channel name</i> | | |
| <i>description</i> | read encoder in 32 bit format | | | | |

SysEncoder_Start

| <i>name</i> | SysEncoder_Start | | | <i>type</i> | <i>Function</i> |
|----------------------|-------------------------|----------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | <i>Function executed successfully.</i> | | |
| | | FALSE | <i>Function skipped.</i> | | |
| <i>input value 1</i> | <i>name</i> | Encoder | | | |
| | <i>type</i> | type_ENCODER | Selects the hardware related encoder channel by name | | |
| | <i>value</i> | {Channel name} | See <i>hardware reference table channel name</i> | | |
| <i>description</i> | Starts counting | | | | |

SysEncoder_Stop

| <i>name</i> | SysEncoder_Stop | | | <i>type</i> | <i>Function</i> |
|----------------------|------------------------|----------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | | | |
| | | FALSE | | | |
| <i>input value 1</i> | <i>name</i> | Encoder | | | |
| | <i>type</i> | type_ENCODER | Selects the hardware related encoder channel by name | | |
| | <i>value</i> | {Channel name} | See <i>hardware reference table channel name</i> | | |
| <i>description</i> | stops counting | | | | |

FBESysFile.lib

| Functions | Description |
|------------------|--|
| SysDirSet | Set a new active directory for file system. All SysFileOpen commands are referred to this directory, if no complete path information is included. Default active directory name is: a:\usr\ |
| SysFileClose | Closes an opened file |
| SysFileCopy | copies a file to a new filename |
| SysFileDelete | deletes a file |
| SysFileEOF | checks if the file pointer is on the end of file position |
| SysFileGetSize | returns file size on a closed file |
| SysFileGetSizeld | returns file size of an opened file |
| SysFileOpen | This function returns a handle to the new file. This handle is the reference for all file access commands. If return value = 0, opening of the file failed |
| SysFileRead | reads data from a file |
| SysFileSetPos | sets the file pointer to a new position |
| SysFileWrite | writes data to a file |

Hardware Reference

| | PLC1010/PLC1210 | PLC1020 / PLC1220 | PLC1030 / PLC1230 |
|------------------------|-----------------|-------------------|-------------------|
| Number of drives | 2 | 2 | 3 |
| default internal drive | a:\ | a:\ | a:\ |
| external drive | c:\ | c:\ | c:\ / d:\ |

SysDirSet

| name | SysDirSet | | | type | Function |
|---------------|--|---------|--|------|----------|
| return value | type | BOOL | | | |
| | value | TRUE | Function ended successfully. | | |
| | | FALSE | Function skipped. | | |
| input value 1 | name | DirName | | | |
| | type | STRING | New active directory | | |
| | value | [path] | specify complete patch with drive letter | | |
| description | This function sets a new active directory for file system. All SysFileOpen commands are referred to this directory, if no complete path information is included. Default active directory name is: C:\USR\ | | | | |

SysFileClose

| name | SysFileClose | | | type | Function |
|---------------|--|---------------|------------------------------|------|----------|
| return value | type | BOOL | | | |
| | value | TRUE | Function ended successfully. | | |
| | | FALSE | Function skipped. | | |
| input value 1 | name | File | | | |
| | type | DWORD | File handle | | |
| | value | [1..FFFFFF]FF | File handle number | | |
| description | This function closes an opened file. File handle will be invalid then. | | | | |

SysFileCopy

| name | SysFileCopy | | | type | Function |
|----------------------|--------------------|-------------------|--------------------------------|-------------|-----------------|
| <i>return value</i> | type | DWORD | | | |
| | value | [1..FFFFFF]F | <i>Number of copied bytes.</i> | | |
| <i>input value 1</i> | name | FileDest | | | |
| | type | STRING | File to create new | | |
| | value | [path / filename] | <i>File name (path)</i> | | |
| <i>input value 2</i> | name | FileSource | | | |
| | type | STRING | File to read | | |
| | value | [path / filename] | <i>File name (path)</i> | | |
| description | Copies a file. | | | | |

SysFileDelete

| name | SysFileDelete | | | type | Function |
|----------------------|--------------------------|-------------------|-------------------------------------|-------------|-----------------|
| <i>return value</i> | type | BOOL | | | |
| | value | TRUE | <i>Function ended successfully.</i> | | |
| | | FALSE | <i>Function skipped.</i> | | |
| <i>input value 1</i> | name | FileName | | | |
| | type | STRING | File to delete | | |
| | value | [path / filename] | <i>File name (path)</i> | | |
| description | Function deletes a file. | | | | |

SysFileEOF

| name | SysFileEOF | | | type | Function |
|----------------------|---|--------------|--|-------------|-----------------|
| <i>return value</i> | type | BOOL | | | |
| | value | TRUE | <i>End of file is reached.</i> | | |
| | | FALSE | <i>End of file is not reached or function skipped.</i> | | |
| <i>input value 1</i> | name | File | | | |
| | type | DWORD | File handle | | |
| | value | [1..FFFFFF]F | <i>File handle number</i> | | |
| description | Returns if current position is the end of file. | | | | |

SysFileGetPos

| name | SysFileGetPos | | | type | Function |
|----------------------|---|--------------|-------------------------------------|-------------|-----------------|
| <i>return value</i> | type | DINT | | | |
| | value | [0..FFFFFF]F | <i>Actual Seek-Pointer of file.</i> | | |
| <i>input value 1</i> | name | File | | | |
| | type | DWORD | File handle | | |
| | value | [1..FFFFFF]F | <i>File handle number</i> | | |
| description | Returns the position of the current file pointer. | | | | |

SysFileGetSize

| name | SysFileGetSize | | | type | Function |
|----------------------|-------------------------------------|-------------------|------------------|-------------|-----------------|
| <i>return value</i> | <i>type</i> | DINT | File size | | |
| | <i>value</i> | [0..FFFFFF]FF | Number of bytes. | | |
| <i>input value 1</i> | name | FileName | | | |
| | <i>type</i> | STRING | File to delete | | |
| | <i>value</i> | [path / filename] | File name (path) | | |
| <i>description</i> | returns file size of an closed file | | | | |

SysFileGetSized

| name | SysFileGetSized | | | type | Function |
|----------------------|-------------------------------------|---------------|--------------------|-------------|-----------------|
| <i>return value</i> | <i>type</i> | DINT | File size | | |
| | <i>value</i> | [0..FFFFFF]FF | Number of bytes. | | |
| <i>input value 1</i> | name | File | | | |
| | <i>type</i> | DWORD | File handle | | |
| | <i>value</i> | [1..FFFFFF]FF | File handle number | | |
| <i>description</i> | returns file size of an opened file | | | | |

SysFileOpen

| name | SysFileOpen | | | type | Function |
|----------------------|---|-------------------|----------------------------|-------------|-----------------|
| <i>return value</i> | <i>type</i> | DWORD | File handle | | |
| | <i>value</i> | [1..FFFFFF]FF | File handle number | | |
| | | [0] | opening of the file failed | | |
| <i>input value 1</i> | name | FileName | | | |
| | <i>type</i> | STRING | File to delete | | |
| | <i>value</i> | [path / filename] | File name (path) | | |
| <i>input value 2</i> | name | Mode | | | |
| | <i>type</i> | STRING | Acces mode | | |
| | <i>value</i> | [r] | read | | |
| | | [w] | write | | |
| | | [a] | append | | |
| <i>description</i> | This function returns a handle of the new file. This handle is the reference for all file access commands. If return value = 0, opening of the file failed. | | | | |

SysFileRead

| name | SysFileRead | | | type | Function |
|----------------------|--------------------|---------------|--------------------------------------|-------------|-----------------|
| <i>return value</i> | <i>type</i> | DWORD | Number of read bytes | | |
| | <i>value</i> | [0..FFFFFF]FF | Bytes read | | |
| <i>input value 1</i> | name | File | | | |
| | <i>type</i> | DWORD | File handle | | |
| | <i>value</i> | [1..FFFFFF]FF | File handle number | | |
| <i>input value 2</i> | name | Buffer | | | |
| | <i>type</i> | DWORD | Address of buffer to save read bytes | | |
| | <i>value</i> | [0..FFFFFF]FF | Address value | | |
| <i>input value 3</i> | name | Size | | | |
| | <i>type</i> | DWORD | Size of Bytes that must be read | | |
| | <i>value</i> | [0..FFFFFF]FF | size value | | |
| <i>description</i> | | | | | |

SysFileSetPos

| name | SysFileSetPos | | | type | Function |
|---------------|--|---------------|------------------------------|------|----------|
| return value | type | BOOL | | | |
| | value | TRUE | Function ended successfully. | | |
| input value 1 | value | FALSE | Function skipped. | | |
| | name | File | | | |
| | type | DWORD | File handle | | |
| input value 2 | value | [1..FFFFFFFF] | File handle number | | |
| | name | Pos | | | |
| | type | DWORD | Position of the file pointer | | |
| value | [1..FFFFFFFF] | | | | |
| description | Set a new position of the file pointer | | | | |

SysFileWrite

| name | SysFileWrite | | | type | Function |
|---------------|--------------|---------------|------------------------------------|------|----------|
| return value | type | DWORD | Number of written bytes | | |
| | value | [0..FFFFFFFF] | Bytes written | | |
| input value 1 | name | File | | | |
| | type | DWORD | File handle | | |
| | value | [1..FFFFFFFF] | File handle number | | |
| input value 2 | name | Buffer | | | |
| | type | DWORD | Address of buffer to write | | |
| | value | [0..FFFFFFFF] | Address value | | |
| input value 3 | name | Size | | | |
| | type | DWORD | Size of Bytes that must be written | | |
| | value | [0..FFFFFFFF] | size value | | |
| description | | | | | |

FBESysInterrupt.lib

The Library FBESysInterrupt.lib is a Library extension for the CoDeSys PLC runtime system and enables implementation of Interrupt services for IEC61131 applications. It is an internal library; all functions are included in the runtime system.

Each Interrupt channel is assigned to a dedicated interrupt input pin. The interrupts are edge sensitive and may be configured to positive, negative or both transitions at the corresponding interrupt input pin. The interrupt priority may be selected from thirtytwo levels.

An interrupt may not only be activated from hardware signal transitions, but also by IEC61131 application software. This feature enables implementation of program units at different CPU priorities.

The following functions are implemented:

| Functions | Description |
|----------------------------|--|
| SysInterrupt_ClrRequest | clears IRQ request flag |
| SysInterrupt_DeleteService | deletes a previously registered IRQ channel. Input can then be used as regular input again |
| SysInterrupt_Disable | disables an IRQ |
| SysInterrupt_Enable | enables an IRQ |
| SysInterrupt_RegService | registers an IRQ in the hipecs operating system |
| SysInterrupt_SetRequest | sets the IRQ request flag in the OS to trigger an interrupt without hardware input |

Hardware Reference

hipecs PLC10XX

| Available Interrupt Channels | 6 |
|------------------------------|--|
| Interrupt Number in CoDeSys | 2 3 4 5 6 7 |
| Hardware Input Pin | IN1.2 IN1.3 IN1.4 IN1.5 IN1.6 IN1.7 |

SysInterrupt_ClrRequest

| name | SysInterrupt_ClrRequest | | | type | Function |
|---------------|--|--------|---|------|----------|
| return value | type | BOOL | | | |
| | value | TRUE | Request successfully cleared | | |
| | | FALSE | Function skipped. Channel number is out of range. | | |
| input value 1 | name | IrqNr | | | |
| | type | UINT | Interrupt channel | | |
| | value | [2..7] | 0..1: reserved for future use. / [2..7] check hardware reference for available Pins | | |
| description | Clears the interrupt request flag of the chosen interrupt channel. | | | | |

SysInterrupt_DeleteService

| name | SysInterrupt_DeleteService | | | type | Function |
|---------------|--|--------|---|------|----------|
| return value | type | BOOL | | | |
| | value | TRUE | Service successfully deleted. | | |
| | | FALSE | Function skipped. Channel number is out of range. | | |
| input value 1 | name | IrqNr | | | |
| | type | UINT | Interrupt channel | | |
| | value | [2..7] | 0..1: reserved for future use. / [2..7] check hardware reference for available Pins | | |
| description | This function deletes the Interrupt service of a requested interrupt channel. To enable the Interrupt again it must be used the function "SYSINTERRUPT_REGSERVICE" and then "SYSINTERRUPT_ENABLE". | | | | |

SysInterrupt_Disable

| <i>name</i> | SysInterrupt_Disable | | | <i>type</i> | <i>Function</i> |
|----------------------|--|--------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | Interrupt channel successfully disabled. | | |
| <i>input value 1</i> | <i>name</i> | IrqNr | | | |
| | <i>type</i> | UINT | Interrupt channel | | |
| | <i>value</i> | [2..7] | 0..1: reserved for future use. / [2..7] check hardware reference for available Pins | | |
| <i>description</i> | Disables an interrupt channel for reception of interrupt requests. | | | | |

SysInterrupt_Enable

| <i>name</i> | SysInterrupt_Enable | | | <i>type</i> | <i>Function</i> |
|----------------------|--|--------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | Interrupt channel successfully enabled. | | |
| <i>input value 1</i> | <i>name</i> | IrqNr | | | |
| | <i>type</i> | UINT | Interrupt channel | | |
| | <i>value</i> | [2..7] | 0..1: reserved for future use. / [2..7] check hardware reference for available Pins | | |
| <i>description</i> | Enables an interrupt channel for reception of interrupt requests. Previously set request bits will be cleared. With registration of the interrupt function, the interrupt keeps still disabled. In order to use this interrupt channel, it must be enabled with this function. The user must take care of the correct handling of registering and enabling of interrupts. This function does not check, whether there is a interrupt task registered to the channel, that should be enabled. | | | | |

SysInterrupt_RegService

| <i>name</i> | SysInterrupt_RegService | | | <i>type</i> | <i>Function</i> |
|----------------------|--|--------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | Interrupt channel successfully enabled. | | |
| <i>input value 1</i> | <i>value</i> | FALSE | Function skipped. Channel number is out of range. | | |
| | <i>name</i> | IrqNr | | | |
| | <i>type</i> | UINT | Interrupt channel | | |
| <i>input value 2</i> | <i>value</i> | [2..7] | 0..1: reserved for future use. / [2..7] check hardware reference for available Pins | | |
| | <i>name</i> | nPOU_ID | | | |
| | <i>type</i> | INT | Number of the program module that must be registered for this interrupt. | | |
| <i>input value 3</i> | <i>value</i> | | Check the CoDeSys Operator INDEXOF(CallMeFromIrq) | | |
| | <i>name</i> | IrqPriority | | | |
| | <i>type</i> | UINT | Priority level of the Interrupt channel / 0 : Lowest Priority 32 : Highest Priority Use with care!!! Priority level 32 is higher than all other interrupt sources. Only for very short interrupt program! | | |
| <i>value</i> | [0..X] | | Note! Only one irq at the same priority | | |
| | <i>name</i> | Edge | | | |
| | <i>type</i> | UINT | Enables the active edge for interrupt activation (Both edges may be enabled at the same time) | | |
| <i>value</i> | [0..3] | | Bit0 Enables/Disables interrupt enable on rising edge of input signal at dedicated interrupt pin Bit1 Enables/Disables interrupt enable on falling edge of input signal at dedicated interrupt pin Setting of the bits is interpreted as follows Bitx = 0 Edge disabled, Interrupt is not activated at this transition Bitx = 1 Edge enabled, Interrupt is activated at this transition | | |
| <i>description</i> | Registers a function for the use with the interrupt control system. Registering of program modules as an interrupt task is done with the individual Id of this module. The Id can be checked with the function "INDEXOF" of the runtime system. With registration of the interrupt function, the interrupt keeps still disabled. In order to use this interrupt channel, it must be enabled with function "SYSINTERRUPT_ENABLE". | | | | |

SysInterrupt_SetRequest

| <i>name</i> | SysInterrupt_Request | | | <i>type</i> | <i>Function</i> |
|----------------------|---|--------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | Request successfully set | | |
| <i>input value 1</i> | <i>value</i> | FALSE | Function skipped. Channel number is out of range. | | |
| | <i>name</i> | IrqNr | | | |
| | <i>type</i> | UINT | Interrupt channel | | |
| <i>value</i> | [2..7] | | 0..1: reserved for future use. / [2..7] check hardware reference for available Pins | | |
| <i>description</i> | Sets the interrupt request flag of a dedicated interrupt channel. If this channel was previously enabled, the interrupt will be called. | | | | |

FBESysPWM.lib

| Functions | Description |
|----------------|--|
| SysPwm_Close | Closes a PWM channel by resetting PWM unit of this channel. Additionally the channel's output will be released. Then it works as in default as standard digital output. |
| SysPwm_Open | Opens a PWM channel by initialisation a output for using with PWM unit. This function must be called once before using any other PWM functions of the corresponding PWM channel. |
| SysPwm_SetDuty | Changes the duty cycle of the selected PWM channel. |
| SysPwm_Start | Starts PWM signal with preset duty cycle. |
| SysPwm_Stop | Stops PWM signal. PWM channel output goes to passive level. |

Hardware Reference

hipecs PLC1000

| | | | |
|-----------------------------------|----------------|----------------|----------------|
| Number of PWM channels | 11 | | |
| Channel number | 0 .. 4 | 5 .. 7 | 8 .. 10 |
| PWM frequency max. (kHz) | 100 | 100 | 1 |
| Resolution max. (steps) | 10000 | 10000 | 10000 |
| Channels uses same base frequency | no | yes | yes |
| Output | DOUT0.0 to 0.4 | DOUT0.5 to 0.7 | DOUT1.0 to 0.2 |

hipecs PLC1000 offers 11 PWM channels. 5 of them have independent clock sources while 3 + 3 use the same base clock. So up to 7 channels can work with different base frequency. Channel 8 to 10 are on the normal speed digital outputs (Out Byte 1). That limits these output frequencies to a maximum of 1 kHz. Do not use higher frequencies for this channels.

SysPwm_Close

| name | SysPwm_Close | | | type | Function |
|---------------|---|------------------|---|------|----------|
| return value | type | BOOL | | | |
| | value | TRUE | Function ended successfully. | | |
| | | FALSE | Function skipped. Channel number is out of range. | | |
| input value 1 | name | Channel | | | |
| | type | UINT | Selects the hardware related PWM channel | | |
| | value | [channel number] | See hardware reference table for channel number | | |
| description | This function closes a PWM channel by resetting PWM unit of this channel. The corresponding output may now be used as regular digital output again. | | | | |

SysPwm_Open

| name | SysPwm_Open | | | type | Function |
|---|--|-----------------------------|--|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | Function ended successfully. | | |
| <i>input value 1</i> | value | FALSE | Function skipped. Channel number is out of range or a input value was 0. | | |
| | name | Channel | | | |
| | type | UINT | Selects the hardware related PWM channel | | |
| <i>input value 2</i> | value | [channel number] | See hardware reference table for channel number | | |
| | name | BaseFrequency | | | |
| | type | UDINT | Selects the hardware related PWM frequency. | | |
| <i>input value 3</i> | value | [1..X] | (Hz) See hardware reference | | |
| | name | Steps | | | |
| | type | UINT | Selects the hardware related PWM resolution. | | |
| <i>input value 4</i> | value | [1..X] | (steps) See hardware reference | | |
| | name | InactivePolarityHigh | | | |
| | type | BOOL | Defines output level at PWM stopped or duty cycle 0%. | | |
| <i>input value 5</i> | value | TRUE | Output level is high | | |
| | value | FALSE | Output level is low | | |
| | name | Option | | | |
| <i>description</i> | type | UINT | Reserved for future use | | |
| | value | - | - | | |
| | This function opens a PWM channel by initialisation a output for using with PWM unit. This function must be called once before using any other PWM functions of the corresponding PWM channel. | | | | |
| <ul style="list-style-type: none"> - The product of BaseFrequency and Steps must be less or equal of 100 MHz. Exceeds the product 100MHz, then the Steps has priority and the resulting frequency is calculated as follow: 100MHz / Steps = PWM-freq. - Not all frequencys are possible. This function calculates and sets PWM frequency as near as possible to the requested. In most cases this result is better with a lower value of Steps. | | | | | |

SysPwm_SetDuty

| name | SysPwm_SetDuty | | | type | Function |
|----------------------|---|------------------|--|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | Function ended successfully. | | |
| <i>input value 1</i> | value | FALSE | Function skipped. Channel is not open or channel number is out of range. | | |
| | name | Channel | | | |
| | type | UINT | Selects the hardware related PWM channel | | |
| <i>input value 2</i> | value | [channel number] | See hardware reference table for channel number | | |
| | name | Duty | | | |
| | type | UINT | New duty cycle value. | | |
| <i>description</i> | value | [0..10000] | (x 0.01%) represents duty cycle as 1/100 % | | |
| | This Function changes the duty cycle of the selected PWM channel. The selected channel must be open. New duty cycles can be set before PWM is started or may be changed while PWM is running. | | | | |

SysPwm_Start

| <i>name</i> | SysPwm_Start | | | <i>type</i> | <i>Function</i> |
|----------------------|---|------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | <i>value</i> | FALSE | <i>Function skipped. Channel is not open or channel number is out of range.</i> | | |
| | <i>name</i> | Channel | | | |
| | <i>type</i> | UINT | Selects the hardware related PWM channel | | |
| | <i>value</i> | [channel number] | See <i>hardware reference table for channel number</i> | | |
| <i>description</i> | This function starts PWM signal with preset duty cycle. | | | | |

SysPwm_Stop

| <i>name</i> | SysPwm_Start | | | <i>type</i> | <i>Function</i> |
|----------------------|--|------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | <i>value</i> | FALSE | <i>Function skipped. Channel is not open or channel number is out of range.</i> | | |
| | <i>name</i> | Channel | | | |
| | <i>type</i> | UINT | Selects the hardware related PWM channel | | |
| | <i>value</i> | [channel number] | See <i>hardware reference table for channel number</i> | | |
| <i>description</i> | This function stops PWM signal generation. PWM channel output switches to passive level. | | | | |

FBESysSmPos.lib

| Functions | Description |
|-------------------------|---|
| SmPos_ChangeRampPara | This function calculates the RAMP parameter for stepper motor channel via e-function and is only need, if the ramp must recalculated with other parameters or for other RampModes in special cases. At normal it is not necessary to use this function. The ramp will be calculated with the SmPos_Open function in default for normal operation. |
| SmPos_CloseAxis | This function closes a axis channel by resetting SMP unit of this channel and re-initialization the corresponding output as default digital output. |
| SmPos_DefHome | Sets the actual AXIS position to home position. For this the pulse counter and actual position value will reset to zero. |
| SmPos_EncAssign | (For future use / not available this time) |
| SmPos_EncRelease | (For future use / not available this time) |
| SmPos_EncStopUse | (For future use / not available this time) |
| SmPos_EncUse | (For future use / not available this time) |
| SmPos_GetActualPos | This function returns actual position of an axis. |
| SmPos_GetActualSettings | This function returns actual setting of several values. (Fstart, Fmax, Fstop) |
| SmPos_GetDemandPos | This function returns actual defined demand position of an axis. |
| SmPos_GetDemandVelocity | This function returns actual demand velocity of an axis in %. |
| SmPos_GetSlip | (For future use / not available this time) |
| SmPos_IsAxisActive | This function returns the active state of axis. It returns TRUE if axis is active. Checks wether the axis is Active. Please Note: Axis might be halted by function SmPos_SetVelocity or by a Master Axis. For Checking for Movement please use function SmPos_IsAxisMoving |
| SmPos_IsAxisMoving | This function returns the actual moving state of axis. |
| SmPos_IsPositionReached | This function returns whether demand position of axis is reached. |
| SmPos_OpenAxis | This function opens and initializes a stepper motor channel for using. It also calculates the RAMP parameter for this channel via e-function. The corresponding outputs will be connected to the SmPos unit. |
| SmPos_SetActualPos | |
| SmPos_SetActualToHome | |
| SmPos_SetDemandPos | |
| SmPos_SetOffset | |
| SmPos_SetVelocity | |
| SmPos_StartMotion | |
| SmPos_StopMotion | |
| SmPos_SyncAxis | |
| SmPos_UnSyncAxis | |

Data types defined for encoder library

```
TYPE SysSmPos_Axis : (
    SMPOS_AXIS0:= 0,
    SMPOS_AXIS1:= 1,
    SMPOS_AXIS2:= 2,
    SMPOS_AXIS3:= 3,
    SMPOS_AXIS4:= 4,
    SMPOS_AXIS5:= 5,
    SMPOS_AXIS6:= 6,
    SMPOS_AXIS7:= 7,
    SMPOS_NOAXIS:= -1
);
```

```
END_TYPE
```

```
TYPE SysSmPos_Position : DINT;
```

END_TYPE

```
TYPE SysSmPos_RampMode : (
    SMPOS_RAMP_EXP3:= 0
);
END_TYPE
```

Hardware Reference

hipecs PLC1000

| | | | | |
|---|---|--------------|--------------|-------------|
| Number of stepper motor channels | 4 | | | |
| Channel number | 0 | 1 | 2 | 3 |
| Channel name | SMPOS_AXIS0 | SMPOS_AXIS1 | SMPOS_AXIS2 | SMPOS_AXIS3 |
| Output Clock | DOUT0.0 | DIN0.1 | DIN0.2 | DIN0.3 |
| Output Direction | DOUT0.4 | DIN0.5 | DIN0.6 | DIN0.7 |
| Ramp Length | [10 .. 500] | | | |
| Ramp Modes | SMPOS_RAMP_EXP3 → $F = Fstart + (Fmax - Fstart) * (1 - \exp(-(3 * i)/RampLength))$ | | | |
| All position values [MinPos .. MaxPos] | [-500000000 .. +500000000] | | | |
| hipecs PLC1000 offers 4 stepper motor channels. Each channel uses 2 outputs. | | | | |
| Frequency limitation depending on start frequency. The maximum output clock frequency and the frequency range are depending on the requested/defined start frequency of the stepper motor. Therefore the following values are relevant. | | | | |
| if Fstart is in range of | resulting ranges of | | | |
| | Fstart | Fstop | Fmax | |
| 0 .. 99 | 50 .. 99 | 50 .. 1450 | 100 .. 1500 | |
| 100 .. 399 | 100 .. 199 | 100 .. 2950 | 150 .. 3000 | |
| 200 .. 399 | 200 .. 399 | 200 .. 5950 | 250 .. 6000 | |
| 400 .. 799 | 400 .. 799 | 400 .. 11950 | 450 .. 12000 | |
| > 800 | 800 .. 23950 | 800 .. 23950 | 850 .. 24000 | |

SmPos_ChangeRampPara

| name | SmPos_ChangeRampPara | | | type | Function |
|---------------|----------------------|-------------------|--|------|----------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | Function ended successfully. | | |
| | | FALSE | Function skipped. Channel number is out of range or an error occurred. | | |
| input value 1 | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | value | [Channel name] | See hardware reference table for axe channel name | | |
| input value 2 | name | RampMode | | | |
| | type | SysSmPos_RampMode | Selects the ramp curve mathematical function | | |
| | value | [Ramp Modes] | See hardware reference for ramp mode | | |
| input value 3 | name | RampLength | | | |
| | type | UINT | Number of ramp steps | | |
| | value | [Ramp Length] | See hardware reference for ramp length | | |
| input value 4 | name | FrequencyStart | | | |
| | type | UINT | Start frequency of stepper motor | | |
| | value | [Fstart] | See hardware reference for start frequency | | |
| input value 5 | name | FrequencyMax | | | |
| | type | UINT | Maximum frequency of stepper motor | | |
| | value | [Fmax] | See hardware reference for maximum frequency | | |

| | | | |
|--------------------|---|----------------------|---|
| input value 6 | name | FrequencyStop | |
| | type | UINT | Stop frequency of stepper motor |
| | value | [Fstop] | See hardware reference for stop frequency |
| description | This function calculates the RAMP parameter for stepper motor channel via e-function and is only need, if the ramp must recalculated with other parameters or for other RampModes in special cases. At normal it is not necessary to use this function. The ramp will be calculated with the SmPos_Open function in default for normal operation. | | |

SmPos_CloseAxis

| name | SmPos_CloseAxis | | | type | Function |
|--------------------|---|----------------|--|-------------|-----------------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | Function ended successfully. | | |
| | | FALSE | Function skipped. Axis channel is not open or channel is out of range. | | |
| input value 1 | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | value | [Channel name] | See hardware reference table for axe channel name | | |
| description | This function closes a axis channel by resetting SMP unit of this channel and re-initialization the corresponding output as default digital output. | | | | |

SmPos_DefHome

| name | SmPos_DefHome | | | type | Function |
|--------------------|---|----------------|--|-------------|-----------------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | Function ended successfully. | | |
| | | FALSE | Function skipped. Axis channel is not open or channel is out of range. | | |
| input value 1 | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | value | [Channel name] | See hardware reference table for axe channel name | | |
| description | Sets the actual AXIS position to home position. For this the puls counter and actual position value will reset to zero. | | | | |

SmPos_EncAssign

(For future use / not available this time)

SmPos_EncRelease

(For future use / not available this time)

SmPos_EncStopUse

(For future use / not available this time)

SmPos_EncUse

(For future use / not available this time)

SmPos_GetActualPos

| name | SmPos_GetActualPos | | | type | Function |
|--------------------|---|--------------------|--|-------------|-----------------|
| return value | type | SysSmPos_Position | Returns the actual position of axis. (signed 32 bit value) | | |
| | value | [MinPos .. MaxPos] | See hardware reference table for position value range | | |
| | | | | | |
| input value 1 | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | value | [Channel name] | See hardware reference table for axe channel name | | |
| description | This function returns actual position of an axis. | | | | |

SmPos_GetActualSettings

| name | SmPos | GetActualSettings | type | Function |
|----------------------|---|--------------------------|---|-----------------|
| <i>return value</i> | <i>type</i> | UDINT | Returns the actual value selected by parameter Selector | |
| | <i>value</i> | [0 .. FFFFFFFF] | Value of the selected parameter. | |
| <i>input value 1</i> | <i>name</i> | Axis | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | |
| | <i>value</i> | [Channel name] | See hardware reference table for axe channel name | |
| <i>input value 2</i> | <i>name</i> | Selector | | |
| | <i>type</i> | UINT | Selects the returned value | |
| | <i>value</i> | 0 | Return value is Fstart (start frequency of stepper motor) | |
| | <i>value</i> | 1 | Return value is Fstop (stop frequency of stepper motor) | |
| | <i>value</i> | 2 | Return value is Fmax (maximum frequency of stepper motor) | |
| <i>description</i> | This function returns actual setting of several values. (Fstart, Fmax, Fstop) | | | |

SmPos_GetDemandPos

| name | SmPos | GetDemandPos | type | Function |
|----------------------|--|-----------------------------|---|-----------------|
| <i>return value</i> | <i>type</i> | SysSmPos_Position | Returns the actual defined demand position of axis. (signed 32 bit value) | |
| | <i>value</i> | [FFFFFFFF .. 0 .. 7FFFFFFF] | Demand position. | |
| <i>input value 1</i> | <i>name</i> | Axis | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | |
| | <i>value</i> | [Channel name] | See hardware reference table for axe channel name | |
| <i>description</i> | This function returns actual defined demand position of an axis. | | | |

SmPos_GetDemandVelocity

| name | SmPos | GetDemandVelocity | type | Function |
|----------------------|---|--------------------------|---|-----------------|
| <i>return value</i> | <i>type</i> | UINT | Returns the actual defined demand velocity of axis. | |
| | <i>value</i> | [0 .. 100] | Demand velocity in %. | |
| <i>input value 1</i> | <i>name</i> | Axis | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | |
| | <i>value</i> | [Channel name] | See hardware reference table for axe channel name | |
| <i>description</i> | This function returns actual demand velocity of an axis in %. | | | |

SmPos_GetSlip

(For future use / not available this time)

SmPos_IsAxisActive

| name | SmPos | IsAxisActive | type | Function |
|----------------------|--|---------------------|---|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the active state. | |
| | <i>value</i> | TRUE | Axis is active. | |
| | <i>value</i> | FALSE | Axis is not active. | |
| <i>input value 1</i> | <i>name</i> | Axis | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | |
| | <i>value</i> | [Channel name] | See hardware reference table for axe channel name | |
| <i>description</i> | This function returns the active state of axis. It returns TRUE if axis is active. Checks whether the axis is Active. Please Note: Axis might be halted by function SmPos_SetVelocity or by a Master Axis. For Checking for Movement please use function SmPos_IsAxisMoving | | | |

SmPos_IsAxisMoving

| <i>name</i> | SmPos_IsAxisMoving | | | <i>type</i> | <i>Function</i> |
|----------------------|--|----------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the actual moving state of axis. | | |
| | <i>value</i> | TRUE | <i>Axis is moving now.</i> | | |
| | | FALSE | <i>Axis is not moving now.</i> | | |
| <i>input value 1</i> | <i>name</i> | Axis | | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | <i>value</i> | [Channel name] | See hardware reference table for axe channel name | | |
| <i>description</i> | This function returns the actual moving state of axis. | | | | |

SmPos_IsPositionReached

| <i>name</i> | SmPos_IsPositionReached | | | <i>type</i> | <i>Function</i> |
|----------------------|---|----------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns whether demand position of axis is reached. | | |
| | <i>value</i> | TRUE | <i>Demand position of Axis is reached.</i> | | |
| | | FALSE | <i>Demand position of Axis is not reached.</i> | | |
| <i>input value 1</i> | <i>name</i> | Axis | | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | <i>value</i> | [Channel name] | See hardware reference table for axe channel name | | |
| <i>description</i> | This function returns whether demand position of axis is reached. | | | | |

SmPos_OpenAxis

| <i>name</i> | SmPos_OpenAxis | | | <i>type</i> | <i>Function</i> |
|----------------------|-----------------------|--------------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| | | FALSE | <i>Function skipped. Axis channel is out of range or an error occurred.</i> | | |
| <i>input value 1</i> | <i>name</i> | Axis | | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | <i>value</i> | [Channel name] | See hardware reference table for axe channel name | | |
| <i>input value 2</i> | <i>name</i> | RampMode | | | |
| | <i>type</i> | SysSmPos_RampMode | Selects the ramp curve mathematical function | | |
| | <i>value</i> | [Ramp Modes] | See hardware reference for ramp mode | | |
| <i>input value 3</i> | <i>name</i> | RampLength | | | |
| | <i>type</i> | UINT | Number of ramp steps | | |
| | <i>value</i> | [Ramp Length] | See hardware reference for ramp length | | |
| <i>input value 4</i> | <i>name</i> | FrequencyStart | | | |
| | <i>type</i> | UINT | Start frequency of stepper motor | | |
| | <i>value</i> | [Fstart] | See hardware reference for start frequency | | |
| <i>input value 5</i> | <i>name</i> | FrequencyMax | | | |
| | <i>type</i> | UINT | Maximum frequency of stepper motor | | |
| | <i>value</i> | [Fmax] | See hardware reference for maximum frequency | | |
| <i>input value 6</i> | <i>name</i> | FrequencyStop | | | |
| | <i>type</i> | UINT | Stop frequency of stepper motor | | |
| | <i>value</i> | [Fstop] | See hardware reference for stop frequency | | |
| <i>input value 7</i> | <i>name</i> | SoftStopPulses | | | |
| | <i>type</i> | UINT | Number of steps that to drive with Fstop before motor stops | | |
| | <i>value</i> | [0 .. FFFF] | Number of soft stop steps | | |
| <i>input value 8</i> | <i>name</i> | Tolerance | | | |
| | <i>type</i> | UINT | motor stops when position is in range of demand position +- tolerance | | |
| | <i>value</i> | [0 .. FFFF] | Number of tolerance steps | | |
| <i>input value 9</i> | <i>name</i> | InvertOutputLevel | | | |
| | <i>type</i> | UINT | Defines the output default level | | |
| | <i>value</i> | [0 .. 1] | <i>if value is greater zero, output level is inverted</i> | | |

| | | | |
|--------------------|--|--|--|
| <i>description</i> | This function opens and initializes a stepper motor channel for using. It also calculates the RAMP parameter for this channel via e-function. The corresponding outputs will be connected to the SmPos unit. | | |
|--------------------|--|--|--|

SmPos_SetActualPos

| <i>name</i> | SmPos_SetActualPos | | | <i>type</i> | Function |
|----------------------|---|---------------------|--|-------------|----------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| | | FALSE | <i>Function skipped. Axis channel is not open or out of range.</i> | | |
| <i>input value 1</i> | <i>name</i> | Axis | | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | <i>value</i> | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| <i>input value 2</i> | <i>name</i> | NewActualPos | | | |
| | <i>type</i> | SysSmPos_Position | <i>New position value</i> | | |
| | <i>value</i> | [MinPos .. MaxPos] | <i>See hardware reference table for position value range</i> | | |
| <i>description</i> | This function changes the actual position to new value. | | | | |

SmPos_SetActualToHome

| <i>name</i> | SmPos_SetActualToHome | | | <i>type</i> | Function |
|----------------------|---|----------------|--|-------------|----------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| | | FALSE | <i>Function skipped. Axis channel is not open or out of range.</i> | | |
| <i>input value 1</i> | <i>name</i> | Axis | | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | <i>value</i> | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| <i>description</i> | This function sets the actual AXIS position to home position. For this the internal pulse counter and actual position value will reset to zero. | | | | |

SmPos_SetDemandPos

| <i>name</i> | SmPos_SetDemandPos | | | <i>type</i> | Function |
|----------------------|---|---------------------|--|-------------|----------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| | | FALSE | <i>Function skipped. Axis channel is not open or out of range.</i> | | |
| <i>input value 1</i> | <i>name</i> | Axis | | | |
| | <i>type</i> | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| | <i>value</i> | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| <i>input value 2</i> | <i>name</i> | NewActualPos | | | |
| | <i>type</i> | SysSmPos_Position | <i>New demand position value</i> | | |
| | <i>value</i> | [MinPos .. MaxPos] | <i>See hardware reference table for position value range</i> | | |
| <i>description</i> | This function changes the demand position to new value. | | | | |

SmPos_SetOffset

| name | SmPos_SetOffset | | | type | Function |
|----------------------|--|--------------------|--|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | value | FALSE | <i>Function skipped. Axis channel is not open or out of range.</i> | | |
| | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| <i>input value 2</i> | value | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| | name | Offset | | | |
| | type | SysSmPos_Position | <i>Offset value that will be added to demand position</i> | | |
| <i>description</i> | value | [MinPos .. MaxPos] | <i>See hardware reference table for position value range</i> | | |
| | This function changes the demand position. The offset value is added to the demand position. If demand position exceeds the range [MinPos .. MaxPos] it will be truncated. | | | | |

SmPos_SetVelocity

| name | SmPos_SetVelocity | | | type | Function |
|----------------------|---|-----------------|--|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | value | FALSE | <i>Function skipped. Axis channel is not open or out of range.</i> | | |
| | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| <i>input value 2</i> | value | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| | name | Velocity | | | |
| | type | UINT | <i>New velocity value</i> | | |
| <i>description</i> | value | [0 .. 100] | <i>Velocity as %</i> | | |
| | This function changes the maximum velocity. | | | | |

SmPos_StartMotion

| name | SmPos_StartMotion | | | type | Function |
|----------------------|---|----------------|--|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | value | FALSE | <i>Function skipped. Axis channel is not open or out of range.</i> | | |
| | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| <i>description</i> | value | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| | This function starts motion of an axis. | | | | |

SmPos_StopMotion

| name | SmPos_StopMotion | | | type | Function |
|----------------------|--|----------------|--|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | value | FALSE | <i>Function skipped. Axis channel is not open or out of range.</i> | | |
| | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| <i>description</i> | value | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| | This function stops motion of an axis. | | | | |

SmPos_SyncAxis

| name | SmPos SyncAxis | | | type | Function |
|----------------------|---|-------------------|--|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | value | FALSE | <i>Function skipped. Axis channel is not open or out of range.</i> | | |
| | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| <i>input value 2</i> | value | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| | name | MasterAxis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| <i>description</i> | value | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| | This function connect the axis for synchronization to an other axis as so, that the axis goes on moving same speed and direction to the master axis. (Note: mater and slave axis must have same initialization for this function) | | | | |

SmPos_UnSyncAxis

| name | SmPos SyncAxis | | | type | Function |
|----------------------|--|----------------|--|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | <i>Function ended successfully.</i> | | |
| <i>input value 1</i> | value | FALSE | <i>Function skipped. Axis channel is not open or out of range.</i> | | |
| | name | Axis | | | |
| | type | SysSmPos_Axis | Selects the hardware related AXIS channel by name | | |
| <i>description</i> | value | [Channel name] | <i>See hardware reference table for axe channel name</i> | | |
| | This function release the axis from synchronization of an other axis. The axis then runs with her own parameter. | | | | |

FBESys_Util.lib

| Functions | Description |
|---------------------|---|
| SysUtil_GetFV | Returns the version number of the internal run time system (example 1234 ==> Version 1.234) |
| SysUtil_GetSysTime | Returns system time. |
| SysUtil_GetTargetId | Returns the target identification for CodeSys development environment |
| SysUtil_LedSet | Sets the lighting state of an programmable LED |
| SysUtil_GetTaskInfo | Returns information about tasks |
| SysUtil_GetSerNo | Returns serial number of the hipecs PLC |

SysUtil_GetFV

| <i>name</i> | SysUtil_GetFV | | | <i>type</i> | <i>Function</i> |
|----------------------|---|--------------|----------------------|-------------|--|
| <i>return value</i> | <i>type</i> | UDINT | | | |
| | | [0...FFFFFF] | | | <i>Version of internal Firmware. (Example 1234 ==> Version 1.234)</i> |
| <i>input value 1</i> | <i>name</i> | Dummy | | | |
| | <i>type</i> | UINT | reserved. | | |
| | <i>value</i> | [0] | Set this always zero | | |
| <i>description</i> | This function returns the Version Number of the internal run time system. | | | | |

SysUtil_GetSysTime

| <i>name</i> | SysUtil_GetSysTime | | | <i>type</i> | <i>Function</i> |
|----------------------|--|--------------|-----------------------------|-------------|-----------------|
| <i>return value</i> | <i>type</i> | UDINT | | | |
| | | [0...FFFFFF] | <i>System time</i> | | |
| <i>input value 1</i> | <i>name</i> | Scale | | | |
| | <i>type</i> | UINT | Time scale ident. | | |
| | <i>value</i> | [0] | Systemtime in milli seconds | | |
| | | [x] | Others reserved | | |
| <i>description</i> | This function returns the system time. | | | | |

SysUtil_GetTargetId

| <i>name</i> | SysUtil_GetTargetId | | | <i>type</i> | <i>Function</i> |
|----------------------|--|------------|------------------------------|-------------|-----------------|
| <i>return value</i> | <i>type</i> | UINT | | | |
| | | [0...FFFF] | <i>Target Identification</i> | | |
| <i>input value 1</i> | <i>name</i> | Dummy | | | |
| | <i>type</i> | UINT | reserved. | | |
| | <i>value</i> | [0] | Set this always zero | | |
| <i>description</i> | Returns the Target Identification for CodeSys development environment. | | | | |

SysUtil_LedSet

| <i>name</i> | SysUtil_LedSet | | | <i>type</i> | <i>Function</i> |
|----------------------|---|---------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE FALSE | Function ended successfully. Function skipped. | | |
| <i>input value 1</i> | <i>name</i> | LED_NR | | | |
| | <i>type</i> | UINT | Selects the hardware LED by number | | |
| | <i>value</i> | [Led_Nr] | See hardware reference table for valid LED number | | |
| <i>input value 2</i> | <i>name</i> | LIGHT | | | |
| | <i>type</i> | SysSmPos_Axis | Defines the lighting state of selected LED | | |
| | <i>value</i> | [‐9...100] | ???? | | |
| <i>description</i> | Sets the lighting state of an programmable LED: negative value: number of flashes positive values: duty cycle | | | | |

SysUtil_GetTaskInfo

| <i>name</i> | SysUtil_GetTaskInfo | | | <i>type</i> | <i>Function</i> |
|----------------------|---|-------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | UINT | Depending on the InfoID (see below) | | |
| | <i>value</i> | [0..X] | IF InfoID=0, function returns task state: 0: undefined 1: running 2: halted | | |
| <i>input value 1</i> | <i>name</i> | TaskID | | | |
| | <i>type</i> | UINT | Id of the requested Task: | | |
| | <i>value</i> | [0 ... 8] | 0: Task, running the PLC_PRG POU 1: Visu Task 2..8: Additional tasks | | |
| <i>input value 2</i> | <i>name</i> | InfoID | | | |
| | <i>type</i> | UDINT | Defines what kind of Information is returned | | |
| | <i>value</i> | [0...2] | 0: function returns task status (see description above) 1: function returns period in ms 2: function returns execution time | | |
| <i>description</i> | Returns task information or period/execution time | | | | |

SysUtil_GetSerNo

| <i>name</i> | SysUtil_GetSerNo | | | <i>type</i> | <i>Function</i> |
|----------------------|---|--------------|-----------------------------|-------------|-----------------|
| <i>return value</i> | <i>type</i> | UDINT | | | |
| | | [0...FFFFFF] | serial number of the system | | |
| <i>input value 1</i> | <i>name</i> | Dummy | | | |
| | <i>type</i> | UINT | reserved. | | |
| | <i>value</i> | [0] | Set this always zero | | |
| <i>description</i> | Returns the serial number of the PLC controller | | | | |

FBESysSerial.lib

| Functions | Description |
|--------------------|---|
| SysCom_Clear | |
| SysCom_Close | |
| SysCom_GetRxBufNum | |
| SysCom_GetStatus | |
| SysCom_Init | |
| SysCom_IsRxReady | |
| SysCom_Read | |
| SysCom_ReadBlock | Reads "Len" characters from the serial port to the buffer at Address until end of string or MaxLen is reached. Returns the number of characters |
| SysCom_ReadString | Reads characters from the serial port to the buffer StringData until end of string or MaxLen is reached |
| SysCom_ReOpen | |
| SysCom_Write | |
| SysCom_WriteBlock | |
| SysCom_WriteString | |
| | |

Hardware Reference

| hipecs PLC1000 | | | |
|---------------------|-------|-------|---------------|
| Available COM-Ports | | | |
| COM Nr. | 1 | 2 | 3 |
| COM Type | RS232 | RS232 | RS232 / RS422 |

| Data types defined for serial library |
|--|
| TYPE type_COM_BAUD : UDINT; END_TYPE |
| TYPE type_COM_DATABITS : INT; END_TYPE |
| TYPE type_COM_PARITY : (COM_PARITY_EVEN:=69, COM_PARITY_ODD:=79, COM_PARITY_NONE:=78,); END_TYPE |
| TYPE type_COM_PORT:(COM1:=1, COM2:=2, COM3:=3, COM4:=4, COM5:=5, COM6:=6); END_TYPE |

```
TYPE
type_COM_STOPBITS : INT;
END_TYPE
```

SysCom_Clear

| <i>name</i> | SysCom_clear | | | <i>type</i> | <i>Function</i> |
|----------------------|--|------------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| | | FALSE | <i>Function skipped.</i> | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | <i>See hardware reference table for valid COM Port</i> | | |
| <i>description</i> | Clears the receiver register and receiver Buffer | | | | |

SysCom_Close

| <i>name</i> | SysCom_close | | | <i>type</i> | <i>Function</i> |
|----------------------|--|------------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE | <i>Function ended successfully.</i> | | |
| | | FALSE | <i>Function skipped.</i> | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | <i>See hardware reference table for valid COM Port</i> | | |
| <i>description</i> | Closes the corresponding COM interface. Receiver and transmitter will be disabled. | | | | |

SysCom_GetRxBufNum

| <i>name</i> | SysCom_GetRxBufNum | | | <i>type</i> | <i>Function</i> |
|----------------------|--|------------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | UINT | Returns the result state. | | |
| | <i>value</i> | [0..?] | <i>Number of received characters</i> | | |
| | | | | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | <i>See hardware reference table for valid COM Port</i> | | |
| <i>description</i> | Function returns the number of received characters | | | | |

SysCom_GetStatus

| <i>name</i> | SysCom_GetStatus | | | | | | | | <i>type</i> | <i>Function</i> | |
|---------------------|--|---------|-------|---------------------------|-------|-------|-------|-------|-------------|-----------------|--|
| <i>return value</i> | <i>type</i> | BYTE | | Returns the result state. | | | | | | | |
| | <i>value</i> | [0..FF] | | State of the Com Port | | | | | | | |
| | | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 | | |
| | | TxOVL | RxOVL | - | - | - | TxRDY | TxEM | RxRDY | | |
| RxRDY | Receiver Ready 1: The COM interface has received one or more characters. 0: There are no received characters stored to the receiver FIFO buffer | | | | | | | | | | |
| TxEM | Transmitter empty 1: There are no more characters in the transmission FIFO buffer. 0: There are characters in the transmitter FIFO | | | | | | | | | | |
| TxRDY | Transmitter Ready 1: The transmitter FIFO buffer is ready for storing additional characters. 0: The transmitter FIFO buffer is full. Do not start any further transmissions. | | | | | | | | | | |

| | | |
|----------------------|--------------------|---|
| | RxOVL | Receiver Overflow 1: There was an overflow of the receiver FIFO buffer. There are some lost characters. 0: No overflow occurred. The Overflow flag is reset after reading the status byte using function SYSCom_GETSTATUS. So this overflow can only be read for one time. |
| | TxOVL | Transmitter Overflow 1: There was an overflow of the transmitter FIFO buffer. There are some lost characters. 0: No overflow occurred. The Overflow flag is reset after reading the status byte using function SYSCom_GETSTATUS. So this overflow can only be read for one time. |
| <i>input value 1</i> | name | ComPort |
| | type | type_COM_PORT |
| | value | COM1, COM2, COM3 |
| | description | See hardware reference table for valid COM Port |
| | | The function returns the status of a serial COM interface in a Byte. |

SysCom_Init

| name | SysCom_Init | | | type | Function |
|----------------------|---|-------------------------|---|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | Com port initialized sucessfully | | |
| | | FALSE | Function skipped. An error occurred. | | |
| <i>input value 1</i> | name | ComPort | | | |
| | type | type_COM_PORT | Selects the hardware related COM channel by name / number | | |
| | value | COM1, COM2, COM3 | See hardware reference table for valid COM Port | | |
| <i>input value 2</i> | name | Baud | | | |
| | type | type_COM_Baud (UDINT) | Selects the baudrate for the selected COM port | | |
| | value | | See data type reference for available baudrates | | |
| <i>input value 3</i> | name | DataBits | | | |
| | type | type_COM_DATABITS (INT) | Number of data bits for the selected COM port | | |
| | value | [0.. X] | | | |
| <i>input value 4</i> | name | Parity | | | |
| | type | type_COM_PARITY | Selects the parity of the serial transmission | | |
| | value | | See data type reference for valid parities | | |
| <i>input value 5</i> | name | StopBits | | | |
| | type | type_COM_STOPBITS (INT) | Selects the number of stopbits used for serial transmission | | |
| | value | [0.. X] | | | |
| <i>description</i> | Initializes a COM interface and opens it for data transfer operations. If the user configures the serial channel within the CoDeSys system configuration dialog, there is no need to call the SYSCom_INIT function. Function only needs to be called once at the beginning and not every PLC cycle. | | | | |

SysCom_IsRxReady

| name | SysCom_IsRxReady | | | type | Function |
|----------------------|---|------------------|---|-------------|-----------------|
| <i>return value</i> | type | BOOL | Returns the result state. | | |
| | value | TRUE | minimum one character is in the receiver buffer | | |
| | | FALSE | receiver buffer empty | | |
| <i>input value 1</i> | name | ComPort | | | |
| | type | type_COM_PORT | Selects the COM Port | | |
| | value | COM1, COM2, COM3 | See hardware reference table for valid COM Port | | |
| <i>description</i> | Check for characters in the receiver buffer. Returns TRUE if minimum one character is in the receiver buffer. | | | | |

SysCom_Read

| name | SysCom Read | | | type | Function |
|----------------------|---|------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | Byte | Character read from buffer | | |
| | <i>value</i> | [0..?] | <i>If return value is 0, then buffer is empty</i> | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | Type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | See hardware reference table for valid COM Port | | |
| <i>description</i> | Reads one character from the receiver FIFO buffer. If there is no received character in the buffer, the function returns "0". | | | | |

SysCom_ReadBlock

| name | SysCom_ReadBlock | | | type | Function |
|----------------------|---|--------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | UINT | The function returns the number of characters of the received string in bytes | | |
| | <i>value</i> | [0..X] | Number of characters received | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | Type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | See hardware reference table for valid COM Port | | |
| <i>input value 2</i> | <i>name</i> | Address | | | |
| | <i>type</i> | UDINT | Destination where the function has to copy the len characters to. | | |
| | <i>value</i> | [Adress] | Address can be defined by the CoDeSys "ADR(variable name)" operation | | |
| <i>input value 3</i> | <i>name</i> | len | | | |
| | <i>type</i> | UINT | Maximum valid length of this string. | | |
| | <i>value</i> | [Length of string] | Length of string can be determined with the GetRxBufNum function | | |
| <i>description</i> | Reads Len characters from the serial port to the buffer at Address until end of string or Len is reached and returns the number of characters | | | | |

SysCom_ReadString

| name | SysCom_ReadString | | | type | Function |
|----------------------|--|-------------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | UINT | The function returns the number of characters of the received string in bytes | | |
| | <i>value</i> | [0..X] | Number of characters received | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | Type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | See hardware reference table for valid COM Port | | |
| <i>input value 2</i> | <i>name</i> | Stringdata | | | |
| | <i>type</i> | STRING | Destination where the function has to copy the string to. | | |
| | <i>value</i> | [String Data] | Destination must be a variable of the string type | | |
| <i>input value 3</i> | <i>name</i> | Maxlen | | | |
| | <i>type</i> | UINT | Maximum valid length of this string. | | |
| | <i>value</i> | [Maximum string length] | | | |
| <i>description</i> | Read a complete String from the receiver FIFO buffer. The string is either terminated with character ZERO or if the maximum string length is exceeded. | | | | |

SysCom_ReOpen

| name | SysCom_ReOpen | | | type | Function |
|----------------------|--|------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE | <i>COM Port reopened successfully</i> | | |
| | | FALSE | <i>Function skipped. An error occurred.</i> | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | Type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | See hardware reference table for valid COM Port | | |
| <i>description</i> | Opens a COM interface again with last parameters. Receiver and transmitter register and buffer will cleared. The functions SYSCom_CLOSE and SYSCom_REOPEN may be used to block serial reception for some time. | | | | |

SysCom_Write

| name | SysCom_Write | | | type | Function |
|----------------------|---|------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Writes a single character to the transmitter FIFO buffer. | | |
| | <i>value</i> | TRUE | <i>Transmission of the data byte was successful</i> | | |
| | | FALSE | <i>Transmission of the data byte failed</i> | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | Type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | See hardware reference table for valid COM Port | | |
| <i>input value 2</i> | <i>name</i> | Data | | | |
| | <i>type</i> | BYTE | <i>Data Byte to transmit</i> | | |
| | <i>value</i> | [00..FF] | | | |
| <i>description</i> | Writes a single character to the transmitter FIFO buffer. | | | | |

SysCom_WriteString

| name | SysCom_WriteString | | | type | Function |
|----------------------|--|-------------------|--|-------------|-----------------|
| <i>return value</i> | <i>type</i> | UINT | The function returns the length of the transmitted string in bytes | | |
| | <i>value</i> | [0.. X] | <i>Number of character transmitted in bytes</i> | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | Type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | See hardware reference table for valid COM Port | | |
| <i>input value 2</i> | <i>name</i> | StringData | | | |
| | <i>type</i> | String | <i>String data to transmit</i> | | |
| | <i>value</i> | [String data] | <i>Variable must be of the string type</i> | | |
| <i>description</i> | Writes a complete string to the transmitter FIFO buffer. The string must be terminated by a character ZERO | | | | |

SysCom_WriteBlock

| <i>name</i> | SysCom_WriteBlock | | | <i>type</i> | <i>Function</i> |
|----------------------|--|--------------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | UINT | The function returns the number of characters of the transmitted string | | |
| | <i>value</i> | [0..X] | Number of characters transmitted | | |
| <i>input value 1</i> | <i>name</i> | ComPort | | | |
| | <i>type</i> | Type_COM_PORT | Selects the COM Port | | |
| | <i>value</i> | COM1, COM2, COM3 | See hardware reference table for valid COM Port | | |
| <i>input value 2</i> | <i>name</i> | Address | | | |
| | <i>type</i> | UDINT | Destination from where the function has to copy the characters from | | |
| | <i>value</i> | [Adress] | Address can be defined by the CoDeSys "ADR(variable name)" operation | | |
| <i>input value 3</i> | <i>name</i> | len | | | |
| | <i>type</i> | UINT | Maximum valid length of this string. | | |
| | <i>value</i> | [Length of string] | Length of string can be determined with the GetRxBufNum function | | |
| <i>description</i> | Writes Len characters from the variable to serial transmit buffer until end of string or Len is reached and returns the number of characters | | | | |

FBESysUSB.lib

Hardware Reference

| hipecs PLC | PLC1010 / PLC1020 | PLC1030 |
|--|-------------------|---------|
| Available USB Ports | 0 | 2 |
| Hardware name / Connector name | USB-1 | USB-2 |
| Note: The hipecs has 2 available ports for each connector. USB-1 is reserved for CoDeSys programming interface and hyperterminal communication. USB-2 is for use with this library and supports 2 separated USB ports in device mode! | | |

SysUSB_Clear

| <i>name</i> | SysUSB_Clear | | | <i>type</i> | <i>Function</i> |
|----------------------|---|--------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE | Port successfully cleared. | | |
| | <i>value</i> | FALSE | Function skipped. An error occurred. | | |
| <i>input value 1</i> | <i>name</i> | Port | | | |
| | <i>type</i> | UINT | Selects the USB channel by number | | |
| | <i>value</i> | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| <i>description</i> | Function clears receive and transmit buffer | | | | |

SysUSB_Close

| <i>name</i> | SysUSB_Clear | | | <i>type</i> | <i>Function</i> |
|----------------------|---|--------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | TRUE | Port successfully closed. | | |
| | <i>value</i> | FALSE | Function skipped. An error occurred. | | |
| <i>input value 1</i> | <i>name</i> | Port | | | |
| | <i>type</i> | UINT | Selects the USB channel by number | | |
| | <i>value</i> | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| <i>description</i> | Function closes a previously installed USB connection | | | | |

SysUSB_IsConnected

| name | SysUSB_IsConnected | | | type | Function |
|---------------|---|--------|---|------|----------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | Port connected | | |
| input value 1 | value | FALSE | Port not connected | | |
| | name | Port | | | |
| | type | UINT | Selects the USB channel by number | | |
| | value | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| description | Function checks if the USB port is connected to another system. | | | | |

SysUSB_IsRxReady

| name | SysUSB_IsRxReady | | | type | Function |
|---------------|---|--------|---|------|----------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | Data pending in receive buffer | | |
| input value 1 | value | FALSE | Receive buffer empty | | |
| | name | Port | | | |
| | type | UINT | Selects the USB channel by number | | |
| | value | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| description | Function check receive buffer for data. | | | | |

SysUSB_Open

| name | SysUSB_Open | | | type | Function |
|---------------|------------------|--------|---|------|----------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | Port successfully opened. | | |
| input value 1 | value | FALSE | Error occurred. No port initialized. | | |
| | name | Port | | | |
| | type | UINT | Selects the USB channel by number | | |
| | value | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| description | Opens a USB port | | | | |

SysUSB_RxBlock

| <i>name</i> | SysUSB RxBlock | | | <i>type</i> | Function Block |
|---|-----------------------|------------------|---|-------------|----------------|
| return value 1 | <i>name</i> | Confirm | | | |
| | <i>type</i> | BOOL | | | |
| | <i>value</i> | FALSE | | | |
| return value 2 | <i>value</i> | TRUE | | | |
| | <i>name</i> | Busy | | | |
| | <i>type</i> | BOOL | Checks if function is still busy. | | |
| return value 3 | <i>value</i> | FALSE | Function block available / not busy. | | |
| | <i>value</i> | TRUE | Function block still busy. | | |
| | <i>name</i> | connected | | | |
| return value 4 | <i>type</i> | BOOL | | | |
| | <i>value</i> | FALSE | | | |
| | <i>value</i> | TRUE | | | |
| input value 1 | <i>name</i> | RxCount | | | |
| | <i>type</i> | UDINT | Returns the number of characters read from the buffer | | |
| | <i>value</i> | [0.. X] | | | |
| input value 2 | <i>name</i> | Port | | | |
| | <i>type</i> | UINT | Selects the USB channel by number | | |
| | <i>value</i> | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| input value 3 | <i>name</i> | Enable | | | |
| | <i>type</i> | BOOL | | | |
| | <i>value</i> | FALSE | | | |
| | <i>value</i> | TRUE | | | |
| input value 4 | <i>name</i> | pData | | | |
| | <i>type</i> | POINTER TO BYTE | Address of the destination | | |
| | <i>value</i> | [..] | | | |
| description | <i>name</i> | BlockSize | | | |
| | <i>type</i> | UDINT | Number of character that are read from the buffer | | |
| | <i>value</i> | [..] | | | |
| description | | | | | |
| Reads "BlockSize" characters from the USB port to the destination at pData until end of string or Len is reached. | | | | | |

SysUSB_RxByte

| <i>name</i> | SysUSB RxByte | | | <i>type</i> | Function |
|--|----------------------|-------------|---|-------------|----------|
| return value | <i>type</i> | BYTE | Returns the first byte of the receiver FIFO buffer | | |
| | <i>value</i> | [..] | Port successfully opened. | | |
| input value 1 | <i>name</i> | Port | | | |
| | <i>type</i> | UINT | Selects the USB channel by number | | |
| | <i>value</i> | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| description | | | | | |
| Reads one character from the receiver buffer | | | | | |

SysUSB_RxString

| name | SysUSB RxString | | | type | Function Block |
|----------------|---|-----------|---|------|----------------|
| return value 1 | name | Confirm | | | |
| | type | BOOL | | | |
| | value | FALSE | | | |
| return value 2 | value | TRUE | | | |
| | name | Busy | | | |
| | type | BOOL | Checks if function is still busy. | | |
| return value 3 | value | FALSE | Function block available. | | |
| | value | TRUE | Function block still busy. | | |
| | name | connected | | | |
| return value 4 | type | BOOL | | | |
| | value | FALSE | | | |
| | value | TRUE | | | |
| return value 4 | name | Strg | | | |
| | type | STRING | Returns the string read from buffer | | |
| | value | [..] | | | |
| return value 5 | name | RxCount | | | |
| | type | UDINT | Returns the number of characters read from the buffer | | |
| | value | [0.. X] | | | |
| input value 1 | name | Port | | | |
| | type | UINT | Selects the USB channel by number | | |
| | value | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| input value 2 | name | Enable | | | |
| | type | BOOL | | | |
| | value | FALSE | | | |
| | value | TRUE | | | |
| input value 4 | name | MaxSize | | | |
| | type | UDINT | Maximum valid length of the string | | |
| | value | [..] | | | |
| description | Reads a complete String from the receiver FIFO buffer. The string is either terminated with character ZERO or if the maximum string length is exceeded. | | | | |

SysUSB_TxBlock

| <i>name</i> | SysUSB TxBlock | | | <i>type</i> | Function Block |
|--------------------|---|------------------|---|-------------|----------------|
| return value 1 | <i>name</i> | Confirm | | | |
| | <i>type</i> | BOOL | | | |
| | <i>value</i> | FALSE | | | |
| return value 2 | <i>name</i> | Busy | | | |
| | <i>type</i> | BOOL | Checks if function is still busy. | | |
| | <i>value</i> | FALSE | Function block available / not busy. | | |
| return value 3 | <i>name</i> | connected | | | |
| | <i>type</i> | BOOL | | | |
| | <i>value</i> | FALSE | | | |
| return value 4 | <i>name</i> | TxCount | | | |
| | <i>type</i> | UDINT | Returns the number of characters written to the buffer | | |
| | <i>value</i> | [0.. X] | | | |
| input value 1 | <i>name</i> | Port | | | |
| | <i>type</i> | UINT | Selects the USB channel by number | | |
| | <i>value</i> | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| input value 2 | <i>name</i> | Enable | | | |
| | <i>type</i> | BOOL | | | |
| | <i>value</i> | FALSE | | | |
| input value 3 | <i>name</i> | pData | | | |
| | <i>type</i> | POINTER TO BYTE | Address from where the function block fetches the data. | | |
| | <i>value</i> | [..] | Check CoDeSys "ADR()" operator. | | |
| input value 4 | <i>name</i> | BlockSize | | | |
| | <i>type</i> | UDINT | Number of character that are written to the buffer. | | |
| | <i>value</i> | [..] | | | |
| <i>description</i> | Writes "BlockSize" characters from a Address until end of string or Len is reached to the buffer of the USB port. | | | | |

SysUSB_TxByte

| <i>name</i> | SysUSB TxByte | | | <i>type</i> | Function |
|--------------------|--|-------------|---|-------------|----------|
| return value | <i>type</i> | BOOL | | | |
| | <i>value</i> | FALSE | A failure occurred. Not byte written. | | |
| | <i>value</i> | TRUE | Data byte successfully written. | | |
| input value 1 | <i>name</i> | Port | | | |
| | <i>type</i> | UINT | Selects the USB channel by number | | |
| | <i>value</i> | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| input value 2 | <i>name</i> | Data | | | |
| | <i>type</i> | BYTE | Byte which is written to the transmit buffer | | |
| | <i>value</i> | [..] | | | |
| <i>description</i> | Write one character to the transmit buffer of the USB port | | | | |

SysUSB_TxString

| name | SysUSB TxString | | | type | Function Block |
|----------------|--|-----------|---|------|----------------|
| return value 1 | name | Confirm | | | |
| | type | BOOL | | | |
| | value | FALSE | | | |
| return value 2 | value | TRUE | | | |
| | name | Busy | | | |
| | type | BOOL | Checks if function is still busy. | | |
| return value 3 | value | FALSE | Function block available. | | |
| | value | TRUE | Function block still busy. | | |
| | name | connected | | | |
| return value 4 | type | BOOL | | | |
| | value | FALSE | | | |
| | value | TRUE | | | |
| return value 4 | name | TxCount | | | |
| | type | UINT | Returns the number of Bytes written to the buffer | | |
| | value | [..] | | | |
| input value 1 | name | Port | | | |
| | type | UINT | Selects the USB channel by number | | |
| | value | [0..X] | 0 is the lower virtual COM Port of a connected PC. 1 is the higher COM. | | |
| input value 2 | name | Enable | | | |
| | type | BOOL | | | |
| | value | FALSE | | | |
| input value 3 | value | TRUE | | | |
| input value 3 | name | Strg | | | |
| | type | STRING | String which is written to the transmit buffer | | |
| | value | [..] | | | |
| description | Write a complete string to the transmit buffer. String must be terminated by a character ZERO. | | | | |

FBESysCAN.lib

| Functions | Description | |
|---------------------|--|--|
| SysCAN_InitBasicCan | Initializes the Basic-CAN-Interface | |
| SysCAN_IsRxMsg | Checks whether there are received CAN frames | |
| SysCan_Receive | | |
| SysCAN_RxMsg | Receives a CAN message | |
| SysCan_Send | | |
| SysCAN_TxMsg | Transmits a CAN message | |

Hardware Reference

| hipecs PLC1010/1020 | | |
|--------------------------|---------------------|---------------------|
| Available CAN Interfaces | | |
| CAN Interface Nr. | 0 | 1 |
| CoDeSys Enumeration | CAN 0 | CAN 1 |
| CAN Mode | CANopen / Basic CAN | CANopen / Basic CAN |

| hipecs CORE10 Modules | | | | |
|--------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| Available CAN Interfaces | | | | |
| CAN Interface Nr. | 0 | 1 | 2 | 3 |
| CoDeSys Enumeration | CAN 0 | CAN 1 | CAN 2 | CAN 3 |
| CAN Mode | CANopen / Basic CAN / J1939 |

Data types defined for Basic CAN library

```
TYPE SYSCAN_CANMSG :
STRUCT
    Id      : UINT;
    Data    : ARRAY[0..7] OF BYTE;
    Len     : UINT;
END_STRUCT
END_TYPE
```

```
TYPE SYSCAN_CANNODE
CAN0:=0,
CAN1:= 1
);
```

```
TYPE SYSCAN_DIR :(
CAN_RXD:=1,(*Indication for receive messages*)
CAN_TXD:=2 (*Indication for transmit messages*)
);
END_TYPE
```

SysCAN_InitBasicCan

| name | SysCAN_InitBasicCan | | | type | Function |
|--------------|---------------------|-------|--------------------------------|------|----------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | Init successful | | |
| | | FALSE | Function skipped. Init failed. | | |

| | | | |
|--------------------|---|----------------|--|
| input value 1 | name | Node | |
| | type | SYSCAN_CANNODE | CAN Interface Number |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface |
| description | Initializes the Basic-CAN-Interface. In order to use Basic-CAN add a CANopen master to the system configuration. Set baud rate within CANopen master. | | |

SysCAN_IsRxMsg

| name | SysCAN_IsRxMsg | | | type | Function |
|--------------------|--|----------------|--|-------------|-----------------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | One or more messages available | | |
| | | FALSE | No message available | | |
| input value 1 | name | Node | | | |
| | type | SYSCAN_CANNODE | CAN Interface Number | | |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| description | Functions check if there is one or more messages in the receiver buffer. | | | | |

SysCAN_Receive

| name | SysCAN_Receive | | | type | Function |
|--------------------|---|-----------------------|--|-------------|-----------------|
| return value | type | BOOL | | | |
| | value | TRUE | | | |
| | | FALSE | | | |
| input value 1 | name | Node | | | |
| | type | SYSCAN_CANNODE | CAN Interface Number | | |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| input value 2 | name | pMsg | | | |
| | type | POINTER TO SYSCAN_MSG | Pointer to the CAN message | | |
| | value | | check CoDeSys "ADR()" operator | | |
| description | Same functionality as SysCAN_RxMsg but realized as function and not as function block | | | | |

SysCAN_RxMsg

| name | SysCAN_RxMsg | | | type | Function Block |
|----------------|---------------------|-----------------------------|---|-------------|-----------------------|
| return value 1 | name | Success | | | |
| | type | BOOL | Returns the result state. | | |
| | value | FALSE | If message contend is invalid | | |
| | | TRUE | If message contend is valid | | |
| return value 2 | name | ID | | | |
| | type | UINT | returns the CAN identifier of the received message | | |
| | value | [0.. X] | | | |
| return value 3 | name | Data | | | |
| | type | ARRAY [0..7] OF BYTE | Data contend of the received message | | |
| | value | [Data bytes of the message] | | | |
| return value 4 | name | Len | | | |
| | type | UINT | returns the number of data bytes that are valid | | |
| | value | [0.. X] | | | |
| return value 5 | name | Flags | | | |
| | type | UINT | Reserved for future use | | |
| | value | [0..X] | | | |
| input value 1 | name | Enable | | | |
| | type | BOOL | Must be True in order to enable this function block | | |
| | value | FALSE | Function block won't be executed | | |
| | | TRUE | Function will be executed | | |

| | | | |
|--------------------|--|----------------|--|
| input value 2 | name | Node | |
| | type | SYSCAN_CANNODE | CAN Interface Number |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface |
| description | Checks whether there is a received message available and returns the CAN message Note: Each message can only be read for one time from the receiver queue Reading of the message deletes the message from the FIFO automatically ! Note: This function only works with 11 Bit identifiers | | |

SysCAN_Send

| name | SysCAN_Send | | | type | Function |
|--------------------|---|-----------------------|--|-------------|-----------------|
| return value | type | BOOL | | | |
| | value | TRUE | | | |
| | | FALSE | | | |
| input value 1 | name | Node | | | |
| | type | SYSCAN_CANNODE | CAN Interface Number | | |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| input value 2 | name | pMsg | | | |
| | type | POINTER TO SYSCAN_MSG | Pointer to the CAN message | | |
| | value | | check CoDeSys "ADR()" operator | | |
| description | Same functionality as SysCAN_RxMsg but realized as function and not as function block | | | | |

SysCAN_TxMsg

| name | SysCAN_TxMsg | | | type | Function Block |
|--------------------|--|-----------------------------|--|-------------|-----------------------|
| return value 1 | name | Success | | | |
| | type | BOOL | Returns the result state. | | |
| | value | FALSE | If message contend is invalid | | |
| | | TRUE | If message contend is valid | | |
| input value 1 | name | Enable | | | |
| | type | BOOL | Must be True in order to enable this function block | | |
| | value | FALSE | Function block won't be executed | | |
| input value 2 | name | Node | | | |
| | type | SYSCAN_CANNODE | CAN Interface Number | | |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| input value 3 | name | ID | | | |
| | type | UINT | CAN identifier for the message | | |
| | value | [0.. X] | | | |
| input value 4 | name | Data | | | |
| | type | ARRAY [0..7] OF BYTE | Data contend of the message | | |
| | value | [Data bytes of the message] | | | |
| input value 5 | name | Len | | | |
| | type | UINT | defines the number of data bytes that are valid | | |
| | value | [0.. X] | | | |
| input value 6 | name | Flags | | | |
| | type | UINT | Reserved for future use | | |
| | value | [0.. X] | | | |
| description | Writes a CAN message to the transmit buffer. Note: This function only works with 11 Bit identifiers | | | | |

SysCAN_CanNodeGetStatus

| <i>name</i> | SysCAN_CanNodeGetStatus | | | <i>type</i> | <i>Function</i> |
|----------------------|--|----------------|---|---|-----------------|
| <i>return value</i> | <i>type</i> | UINT | | | |
| | <i>value</i> | [0...FFFF] | | <i>Bit 0 : 1 if node is running</i> <i>Bit6 : 1 if node is in error warning state</i> <i>Bit7 : 1 if the node is in bus off error state</i> | |
| <i>input value 1</i> | <i>name</i> | Node | | | |
| | <i>type</i> | SYSCAN_CANNODE | CAN Interface Number | | |
| | <i>value</i> | CAN 0, CAN 1 | <i>See hardware reference table for valid CAN interface</i> | | |
| <i>description</i> | Returns the state of the CAN hardware module | | | | |

SysCAN_CanNodeRecover

| <i>name</i> | SysCAN_Recover | | | <i>type</i> | <i>Function</i> |
|----------------------|---|----------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | <i>recovering procedure startet</i> | | |
| | | FALSE | <i>starting of recovering procedure not successful</i> | | |
| <i>input value 1</i> | <i>name</i> | Node | | | |
| | <i>type</i> | SYSCAN_CANNODE | CAN Interface Number | | |
| | <i>value</i> | CAN 0, CAN 1 | <i>See hardware reference table for valid CAN interface</i> | | |
| <i>description</i> | Function tries to recover a SYSCAN_CANNODE from bus off error | | | | |

SysCAN_CanNodeRecover

| <i>name</i> | SysCAN_Recover | | | <i>type</i> | <i>Function</i> |
|----------------------|---|-----------------|---|-------------|-----------------|
| <i>return value</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | TRUE | <i>recovering procedure startet</i> | | |
| | | FALSE | <i>starting of recovering procedure not successful</i> | | |
| <i>input value 1</i> | <i>name</i> | Node | | | |
| | <i>type</i> | SYSCAN_CANNODE | CAN Interface Number | | |
| | <i>value</i> | CAN 0, CAN 1 | <i>See hardware reference table for valid CAN interface</i> | | |
| <i>input value 2</i> | <i>name</i> | NodeId | | | |
| | <i>type</i> | UINT | <i>New node ID for CANopen interface</i> | | |
| | <i>value</i> | 0...127 | <i>0 : Node-ID will not be changed</i> | | |
| <i>input value 3</i> | <i>name</i> | CANBaud | | | |
| | <i>type</i> | UDINT | <i>New baud rate for CAN interface</i> | | |
| | <i>value</i> | [0...1.000.000] | <i>0 : Baud rate will not be changed</i> | | |
| <i>description</i> | This function reconfigs the CAN bus interface. The bus must have been initialized using the system configuration dialog. If you do not want to start the bus before calling reconfig from PLC application use CANopen node ID = 127. It is recommended to use this function only in the main task calling PLC_PRG | | | | |

SysCAN29Bit_IsRxMsg

| name | SysCAN29Bit_IsRxMsg | | | type | Function |
|---------------|---|----------------|--|------|----------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | One or more messages available | | |
| | | FALSE | No message available | | |
| input value 1 | name | Node | | | |
| | type | SYSCAN_CANNODE | CAN Interface Number | | |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| description | Function checks if there is one or more messages with 29 Bit Identifier in the receiver buffer. | | | | |

SysCAN29Bit_Send

| name | SysCAN29Bit_Send | | | type | Function |
|---------------|---|----------------------------------|--|------|----------|
| return value | type | BOOL | | | |
| | value | TRUE | | | |
| | | FALSE | | | |
| input value 1 | name | Node | | | |
| | type | SYSCAN_CANNODE | CAN Interface Number | | |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| input value 2 | name | pMsg | | | |
| | type | POINTER TO SYSCAN29BIT_CANMSG | Pointer to the 29 bit identifier CAN message | | |
| | value | | check CoDeSys "ADR()" operator | | |
| description | Same functionality as SysCAN_RxMsg but for 29 bit identifiers | | | | |

SysCAN29Bit_Receive

| name | SysCAN29Bit_Receive | | | type | Function |
|---------------|---|----------------------------------|--|------|----------|
| return value | type | BOOL | | | |
| | value | TRUE | | | |
| | | FALSE | | | |
| input value 1 | name | Node | | | |
| | type | SYSCAN_CANNODE | CAN Interface Number | | |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| input value 2 | name | pMsg | | | |
| | type | POINTER TO SYSCAN29BIT_CANMSG | Pointer to the 29 bit identifier CAN message | | |
| | value | | check CoDeSys "ADR()" operator | | |
| description | Same functionality as SysCAN_RxMsg but for 29 bit identifiers | | | | |

SYSCI405.lib

The run time system includes a very powerful CANopen master. The CANopen interface is based on a two level software structure. Adding a CANopen master to the PLC configuration activates the lower level according to DS302 level. This layer handles the complete network boot up and PDO transfer automatically.

The second level according to DS405 establishes an interface for the IEC61131 application to the CANopen layer. This layer is implemented in the "FBE_CIA405.lib" library file.

Configuration:

The configuration of this master is done with the CoDeSys PLC configuration dialog. The master is enabled if there is a CANopen master added to the system configuration. The functionality and the maximum number of slaves depends on the target system.

Note: The hipecs supports two separated CAN busses, so the "CanNode" parameter is necessary to choose the right CAN interface. If only one CAN bus is used, it is possible to use the SysCia405_StdBus0.lib library, which has no "CanNode" parameter and always works with the CAN interface 0. This is the IEC conform library, since the IEC only defines a device with a single CAN interface.

Hardware Reference

hipecs PLC1010/1020

Available CAN Interfaces

| | | |
|---------------------|---------------------|---------------------|
| CAN Interface Nr. | 0 | 1 |
| CoDeSys Enumeration | CAN 0 | CAN 1 |
| CAN Mode | CANopen / Basic CAN | CANopen / Basic CAN |

hipecs CORE10 Modules

Available CAN Interfaces

| | | | | |
|---------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| CAN Interface Nr. | 0 | 1 | 2 | 3 |
| CoDeSys Enumeration | CAN 0 | CAN 1 | CAN 2 | CAN 3 |
| CAN Mode | CANopen / Basic CAN / J1939 |

Data types defined for CANopen CiA DS405 library

```
TYPE
    SysCiA405_CANopen_Kernel_Error : WORD;
END_TYPE

TYPE
    SysCiA405_Device: USINT (0..127);
END_TYPE

TYPE SysCiA405_EMCY_Error :
STRUCT
    EMY_ERROR_CODE      : WORD;
    ERROR_REGISTER     : BYTE;
    ERROR_FIELD        : ARRAY[1..5] OF BYTE;
END_STRUCT
END_TYPE

TYPE
    SysCiA405_SDO_Error : UDINT;
END_TYPE

TYPE SysCiA405_State : (
    INIT:= 0,
    RESET_COMM:= 7,
    RESET_APP:= 6,
    PRE_OPERATIONAL:= 127,
    STOPPED:= 4,
    OPERATIONAL:= 5,
    UNKNOWN:= 8,
    NOT_AVAIL:= 1
);
END_TYPE
```

```
TYPE SysCiA405_Transition_State : (
    START_REMOTE_NODE:= 16#01,
    STOP_REMOTE_NODE:= 16#02,
    ENTER_PRE_OPERATIONAL:= 16#80,
    RESET_NODE:= 16#81,
    RESET_COMMUNICATION:= 16#82
);
END_TYPE
```

SysCiA405_Get_Kernel_State

| <i>name</i> | SysCiA405_Get_Kernel_State | | | <i>type</i> | Function Block |
|--------------------|---|--------------------------------|---|-------------|----------------|
| return value 1 | <i>name</i> | CONFIRM | | | |
| | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | FALSE | An error occurred. Return values are invalid! | | |
| | | TRUE | Function successfully completed. Return values are valid. | | |
| return value 2 | <i>name</i> | STATE | | | |
| | <i>type</i> | SysCiA405_CANopen_kernel_Error | Returns the state of the CANopen kernel software | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| input value 1 | <i>name</i> | CanNode | | | |
| | <i>type</i> | UINT | CAN Interface Number | | |
| | <i>value</i> | [0, 1] | See hardware reference table for valid CAN interface | | |
| input value 2 | <i>name</i> | Enable | | | |
| | <i>type</i> | BOOL | Must be True in order to enable this function block | | |
| | <i>value</i> | FALSE | Function block won't be executed | | |
| <i>description</i> | Reads the error state of the CANopen kernel driver. The implementation is done as function block. This will cause the automatic implementation of a data structure according to the parameters. | | | | |

SysCiA405_Get_Local_Node_Id

| <i>name</i> | SysCiA405_Get_Local_Node_Id | | | <i>type</i> | Function Block |
|--------------------|---|--------------------------|---|-------------|----------------|
| return value 1 | <i>name</i> | CONFIRM | | | |
| | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | FALSE | An error occurred. Return values are invalid! | | |
| | | TRUE | Function successfully completed. Return values are valid. | | |
| return value 2 | <i>name</i> | Device | | | |
| | <i>type</i> | SysCiA405_Device (USINT) | Returns the node ID of the device | | |
| | <i>value</i> | [0..127] | | | |
| input value 1 | <i>name</i> | CanNode | | | |
| | <i>type</i> | UINT | CAN Interface Number | | |
| | <i>value</i> | [0, 1] | See hardware reference table for valid CAN interface | | |
| input value 2 | <i>name</i> | Enable | | | |
| | <i>type</i> | BOOL | Must be True in order to enable this function block | | |
| | <i>value</i> | FALSE | Function block won't be executed | | |
| <i>description</i> | Function returns the Node ID of the device. | | | | |

SysCiA405_Get_State

| name | SysCiA405_Get_State | | | type | Function Block |
|----------------|---------------------|---|---|------|----------------|
| return value 1 | name | CONFIRM | | | |
| | type | BOOL | Returns the result state. | | |
| | value | FALSE | An error occurred. Return values are invalid! | | |
| return value 2 | value | TRUE | Function successfully completed. Return values are valid. | | |
| | name | State | | | |
| | type | SysCiA405_State | Returns NMT state of the selected device. | | |
| input value 1 | value | [..] | Check data type reference for available values. | | |
| | name | CanNode | | | |
| | type | UINT | CAN Interface Number | | |
| input value 2 | value | [0, 1] | See hardware reference table for valid CAN interface | | |
| | name | Device | | | |
| | type | SysCiA405_Device (USINT) | Number of the CAN Node. Node ID. | | |
| input value 3 | value | [0..127] | | | |
| | name | Enable | | | |
| | type | BOOL | Must be True in order to enable this function block | | |
| description | value | FALSE | Function block won't be executed | | |
| | value | TRUE | Function will be executed | | |
| | description | Reads the NMT state of a selected CANopen node. The implementation is done as function block. This will cause the automatic implementation of a data structure according to the parameters. | | | |

SysCiA405_Is_Any_EMCY

| name | SysCiA405_Is_Any_EMCY | | | type | Function |
|---------------|---|--------|---|------|----------|
| return value | type | BOOL | The function checks if there are any emergency messages stored in the emergency FIFO memory | | |
| | value | TRUE | One or more emergency messages pending | | |
| | | FALSE | No emergency | | |
| input value 1 | name | Node | | | |
| | type | UINT | CAN Interface Number | | |
| | value | [0, 1] | See hardware reference table for valid CAN interface | | |
| input value 2 | name | Enable | | | |
| | type | BOOL | Must be True in order to enable this function | | |
| | value | FALSE | Function won't be called | | |
| | value | TRUE | Function will be called | | |
| description | Checks whether there are any emergencies stored in the emergency FIFO memory. | | | | |

SysCiA405_NMT

| <i>name</i> | SysCiA405_NMT | | | <i>type</i> | Function Block |
|-----------------------|---|---------------------------------------|--|-------------|----------------|
| <i>return value 1</i> | <i>name</i> | CONFIRM | | | |
| | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | FALSE | An error occured. Return values are invalid! | | |
| | | TRUE | Function successfully completed. Return values are valid. | | |
| <i>return value 2</i> | <i>name</i> | ERROR | | | |
| | <i>type</i> | SysCiA405_CANopen_Kernel_Error (WORD) | Returns the CANopen Error Code if NMT transmission failed. | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| <i>input value 1</i> | <i>name</i> | CanNode | | | |
| | <i>type</i> | UINT | CAN Interface Number | | |
| | <i>value</i> | [0, 1] | See hardware reference table for valid CAN interface | | |
| <i>input value 2</i> | <i>name</i> | Device | | | |
| | <i>type</i> | SysCiA405_Device (USINT) | Number of the CAN Node. Node ID. | | |
| | <i>value</i> | [0..127] | | | |
| <i>input value 3</i> | <i>name</i> | State | | | |
| | <i>type</i> | SysCiA405_Transition_State | Defines the new state for selected Node | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| <i>input value 4</i> | <i>name</i> | Enable | | | |
| | <i>type</i> | BOOL | Must be True in order to enable this function | | |
| | <i>value</i> | FALSE | Function won't be called | | |
| | | TRUE | Function will be called | | |
| <i>description</i> | Sends a NMT command to the CANopen network. This command may be used, if slaves transition states must be changed while the network is still running. | | | | |

SysCiA405_Recv_EMCY

| <i>name</i> | SysCiA405_Recv_EMCY | | | <i>type</i> | Function Block |
|-----------------------|--|---------------------------------------|---|-------------|----------------|
| <i>return value 1</i> | <i>name</i> | CONFIRM | | | |
| | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | FALSE | An error occured. Return values are invalid! | | |
| | | TRUE | Function successfully completed. Return values are valid. | | |
| <i>return value 2</i> | <i>name</i> | Device | | | |
| | <i>type</i> | SysCiA405_Device (USINT) | Number of the CAN Node. Node ID. | | |
| | <i>value</i> | [0..127] | | | |
| <i>return value 3</i> | <i>name</i> | Error | | | |
| | <i>type</i> | SysCiA405_CANopen_Kernel_Error (WORD) | Returns the state of the CANopen kernel software | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| <i>return value 4</i> | <i>name</i> | EMY_ERROR | | | |
| | <i>type</i> | SysCiA405_EMCY_Error | Emergency message of the CANopen node | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| <i>input value 1</i> | <i>name</i> | CanNode | | | |
| | <i>type</i> | UINT | CAN Interface Number | | |
| | <i>value</i> | [0, 1] | See hardware reference table for valid CAN interface | | |
| <i>input value 2</i> | <i>name</i> | Enable | | | |
| | <i>type</i> | BOOL | Must be True in order to enable this function | | |
| | <i>value</i> | FALSE | Function won't be called | | |
| | | TRUE | Function will be called | | |
| <i>description</i> | Reads the oldest emergency message stored in the emergency FIFO memory. Reading of an emergency will also delete this message from the FIFO memory, so each message can only be read once. The implementation is done as function block. This will cause the automatic implementation of a data structure according to the parameters. The Function may either return an emergency sent by a slave (external emergency) or an emergency created from the CANopen Master itself (internal emergency). | | | | |

External Emergency:

Sent by an external CANopen slave. In this case the Variable EMY_ERROR exactly represents the values transmitted by the connected Slave.

| Name | Data-Type | Description |
|---------------------|---------------------------------------|---|
| DEVICE | SysCIA405_Device (USINT) | Node ID of the CANopen node that produced this emergencies |
| ERROR | SysCIA405_CANopen_Kernel_Error (WORD) | State of the CANopen kernel software. |
| EMY_ERROR. | SysCIA405_EMCY_Error | Emergency message of the CANopen node. |
| Emy_Error_Code | | Error Code sent from the slave within the emergency message |
| Error_Register | | Error Register sent from the slave within the emergency message |
| Error_Field[1]..[5] | | Error Field sent from the slave within the emergency message |

Internal Emergency:

Created from the CANopen master. In this case the Variable EMY_ERROR shows the slave number that caused the Emergency of the master.

| Name | Data-Type | Description |
|---------------------|-----------------------------|---|
| DEVICE | CIA405_DEVICE | 0: Always zero to indicate, that the emergency was created from the master firmware and not transmitted over the CAN network |
| ERROR | CIA405_CANOPEN_KERNEL_ERROR | State of the CANopen kernel software. |
| EMY_ERROR. | CIA405_EMY_ERROR | Emergency message of the CANopen master. |
| Emy_Error_Code | | Error Code created from the master firmware |
| Error_Register | | 1: Error is set 0: Information for no Error (or automatically fixed error) |
| Error_Field[1] | | Slave-ID that caused the emergency For example if the node guarding of a connected slave fails, the node ID of this slave is reported in Error_Field[1]. |
| Error_Field[2]..[5] | | 0x00000000 The CANopen master was not able to check the exact reason for the emergency. For example bus errors or distortions may cause such entries in the emergency FIFO. 0x00000001 There was a guarding error detected at this slave (node guarding or heartbeat will not be distinguished) 0x00000002 The slave answered a SDO transfer with an Abort SDO message other codes reserved for future use |

SysCiA405_Recv_EMCY_Dev

| <i>name</i> | SysCiA405_Recv_EMCY_Dev | | | <i>type</i> | Function Block |
|-----------------------|--------------------------------|---------------------------------------|---|-------------|----------------|
| <i>return value 1</i> | <i>name</i> | CONFIRM | | | |
| | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | FALSE | An error occurred. Return values are invalid! | | |
| | | TRUE | Function successfully completed. Return values are valid. | | |
| <i>return value 2</i> | <i>name</i> | Error | | | |
| | <i>type</i> | SysCiA405_CANopen_Kernel_Error (WORD) | Returns the state of the CANopen kernel software | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| <i>return value 3</i> | <i>name</i> | EMY_ERROR | | | |
| | <i>type</i> | SysCiA405_EMCY_Error | Emergency message of the CANopen node | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| <i>input value 1</i> | <i>name</i> | CanNode | | | |
| | <i>type</i> | UINT | CAN Interface Number | | |
| | <i>value</i> | [0, 1] | See hardware reference table for valid CAN interface | | |
| <i>return value 2</i> | <i>name</i> | Device | | | |
| | <i>type</i> | SysCiA405_Device (USINT) | Number of the CAN Node. Node ID. | | |
| | <i>value</i> | [0..127] | | | |
| <i>input value 3</i> | <i>name</i> | Enable | | | |
| | <i>type</i> | BOOL | Must be True in order to enable this function | | |
| | <i>value</i> | FALSE | Function won't be called | | |
| | | TRUE | Function will be called | | |
| <i>description</i> | | | | | |

SysCiA405_SDO_READ4

| <i>name</i> | SysCiA405_SDO_READ4 | | | <i>type</i> | Function Block |
|-----------------------|----------------------------|---------------------------------------|---|-------------|----------------|
| <i>return value 1</i> | <i>name</i> | CONFIRM | | | |
| | <i>type</i> | BOOL | Returns the result state. | | |
| | <i>value</i> | FALSE | An error occurred. Return values are invalid! | | |
| | | TRUE | Function successfully completed. Return values are valid. Check ERRORINFO to verify SDO was read correct. | | |
| <i>return value 2</i> | <i>name</i> | Error | | | |
| | <i>type</i> | SysCiA405_CANopen_Kernel_Error (WORD) | Returns the state of the CANopen kernel software. | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| <i>return value 3</i> | <i>name</i> | ERRORINFO | | | |
| | <i>type</i> | SysCiA405_SDO_Error (UDINT) | Abort Code in case of the SDO transfer fails. Zero if the SDO transfer was successfully completed and the data is valid | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| <i>return value 4</i> | <i>name</i> | DATA | | | |
| | <i>type</i> | ARRAY [1..4] OF BYTE | Data field representing the result of the SDO transmission. | | |
| | <i>value</i> | [4 data bytes] | The data must be converted to the requested data type by calling the corresponding typecast function. | | |
| <i>return value 5</i> | <i>name</i> | DATALENGTH | | | |
| | <i>type</i> | USDINT | Length of the valid data field. | | |
| | <i>value</i> | [0..4] | | | |
| <i>input value 1</i> | <i>name</i> | CanNode | | | |
| | <i>type</i> | UINT | CAN Interface Number | | |
| | <i>value</i> | [0, 1] | See hardware reference table for valid CAN interface | | |
| <i>input value 2</i> | <i>name</i> | Device | | | |
| | <i>type</i> | SysCiA405_Device (USINT) | Number of the CAN Node. Node ID. | | |
| | <i>value</i> | [0..127] | | | |

| | | | |
|--------------------|--|-----------------|---|
| input value 3 | name | INDEX | |
| | type | WORD | Index of the object to be read |
| | value | [0..X] | |
| input value 4 | name | SUBINDEX | |
| | type | BYTE | Subindex of the object to be read |
| | value | [0..X] | |
| input value 5 | name | Enable | |
| | type | BOOL | Must be True in order to enable this function |
| | value | FALSE | Function won't be called |
| | | TRUE | Function will be called |
| description | Read data from a slave node using SDO transfer. Maximum size of data is 4 bytes. The implementation is done as function block. This will cause the automatic implementation of a data structure according to the parameters. | | |

SysCiA405_SDO_WRITE4

| name | SysCiA405_SDO_WRITE4 | | | type | Function Block |
|--------------------|---|---------------------------------------|---|-------------|----------------|
| return value 1 | name | CONFIRM | | | |
| | type | BOOL | Returns the result state. | | |
| | value | FALSE | An error occurred. Return values are invalid! | | |
| | | TRUE | Function successfully completed. Return values are valid. Check ERRORINFO to verify SDO was read correct. | | |
| return value 2 | name | Error | | | |
| | type | SysCiA405_CANopen_Kernel_Error (WORD) | Returns the state of the CANopen kernel software. | | |
| | value | [..] | Check data type reference for available values. | | |
| return value 3 | name | ERRORINFO | | | |
| | type | SysCiA405_SDO_Error (UDINT) | Abort Code in case of the SDO transfer fails. Zero if the SDO transfer was successfully completed and the data is valid | | |
| | value | [..] | Check data type reference for available values. | | |
| input value 1 | name | CanNode | | | |
| | type | UINT | CAN Interface Number | | |
| | value | [0, 1] | See hardware reference table for valid CAN interface | | |
| input value 2 | name | Device | | | |
| | type | SysCiA405_Device (USINT) | Number of the CAN Node. Node ID. | | |
| | value | [0..127] | | | |
| input value 3 | name | INDEX | | | |
| | type | WORD | Index of the object to be written | | |
| | value | [0..X] | | | |
| input value 4 | name | SUBINDEX | | | |
| | type | BYTE | Subindex of the object to be written | | |
| | value | [0..X] | | | |
| input value 5 | name | DATA | | | |
| | type | ARRAY [1..4] OF BYTE | Data field representing the result of the SDO transmission. | | |
| | value | [4 data bytes] | The data must be converted to the BYTE data type by calling the corresponding typecast function. | | |
| input value 6 | name | DATALENGTH | | | |
| | type | USDINT | Length of the valid data field. | | |
| | value | [0..4] | | | |
| input value 7 | name | Enable | | | |
| | type | BOOL | Must be True in order to enable this function | | |
| | value | FALSE | Function won't be called | | |
| | | TRUE | Function will be called | | |
| description | Write data to a slave node using SDO transfer. Maximum size of data is 4 bytes. The implementation is done as function block. This will cause the automatic implementation of a data structure according to the parameters. | | | | |

FBESysTask.lib

The Library FBESysTask.lib is a Library extension for the CoDeSys PLC runtime system and returns the processing / interval time of the last cycle for the chosen task.

SysTask_GetTimeCycle

| <i>name</i> | SysTask_GetTimeCycle | | | <i>type</i> | <i>Function</i> |
|----------------------|--|---------------|--|--|-----------------|
| <i>return value</i> | <i>type</i> | UINT | | Returns the interval time of the last cycle for this task in milli seconds | |
| | <i>value</i> | [0..X] | | | |
| <i>input value 1</i> | <i>name</i> | TaskId | | | |
| | <i>type</i> | UINT | | 0: PLC_PRG Task; 1: Visu_Task; | |
| | <i>value</i> | [0..X] | | | |
| <i>description</i> | Returns the interval time of the last cycle for this task in milli seconds | | | | |

SysTask_GetProcessTime

| <i>name</i> | SysTask_GetProcessTime | | | <i>type</i> | <i>Function</i> |
|----------------------|--|---------------|--|--|-----------------|
| <i>return value</i> | <i>type</i> | UINT | | Returns the processing time of the last cycle for this task in milli seconds | |
| | <i>value</i> | [0..X] | | | |
| <i>input value 1</i> | <i>name</i> | TaskId | | | |
| | <i>type</i> | UINT | | 0: PLC_PRG Task; 1: Visu_Task; | |
| | <i>value</i> | [0..X] | | | |
| <i>description</i> | Returns the processing time of the last cycle for this task in milli seconds | | | | |

FBESysNet.lib

Hardware Reference

hipecs PLC

| hipecs hardware version | PLC 1010 | PLC1020 | PLC1030 |
|-------------------------------|----------|---------|---------|
| Available Ethernet Interfaces | none | 1 | 1 |

Data types defined for FBESysNet.lib library

```
TYPE tSYSNET_EMAIL :  
STRUCT  
    Confirm : BOOL; (*Set TRUE if transmission completed *)  
    Success : BOOL; (*True if email was sent, FALSE if transmission failed *)  
    ErrCode : UINT; (*Errorcode for Transmission *)  
    MailData : ARRAY[0..16#1000] OF UINT; (* Data Reservation for library use, do not modify  
                                            Maximum mail size is 8 kByte (Text apporx 7 kByte *)  
END_STRUCT  
END_TYPE
```

```
TYPE tSYSNET_HttpScriptCtrl :  
STRUCT  
    SourceLine : STRING(255); (* String that is read from the CGI file and must be processed *)  
    DestinLine : STRING(255); (* Output String of the CGI-Processor *)  
    MaxLen : UINT; (* Maximum Len of DestinLine *)  
    pCgiData : POINTER TO UDINT; (* This UDINT variable is for CGI processors internal use *)  
END_STRUCT  
END_TYPE
```

```
TYPE tSYSNET_NetConfig :  
STRUCT  
    HostName : STRING(15); (* Name of the network host we want to setup *)  
    MAC : ARRAY[1..6] OF USINT; (* MAC address for network Interface *)  
    IP : ARRAY[1..4] OF USINT; (* IP address for network host *)  
    MASK : ARRAY[1..4] OF USINT; (* Sub net mask for local network area *)  
    GW : ARRAY[1..4] OF USINT; (* IP address of standard gateway for internet DNS access etc *)  
    PDNS : ARRAY[1..4] OF USINT; (* IP address of primary DNS server *)  
    SDNS : ARRAY[1..4] OF USINT; (* IP address of secondary DNS server *)  
    UseDHCP : BOOL; (* if TRUE the network driver uses DHCP service to get an IP address *)  
END_STRUCT  
END_TYPE
```

SysNet_EmailCreate

| <i>name</i> | SysNet_EmailCreate | | | <i>type</i> | <i>Function</i> |
|--------------------|---|---------------|---|-------------|-----------------|
| return value 1 | <i>type</i> | BOOL | Initializes the mail data for the new mail. | | |
| | <i>value</i> | FALSE | Function skipped. An error occurred. | | |
| | | TRUE | Mail data successfully initialized | | |
| input value 1 | <i>name</i> | eMail | | | |
| | <i>type</i> | tSYSNET_EMAIL | | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| input value 2 | <i>name</i> | eEmailAddress | | | |
| | <i>type</i> | STRING (64) | eMail-Address of recipient | | |
| | <i>value</i> | [..] | | | |
| input value 3 | <i>name</i> | Subject | | | |
| | <i>type</i> | STRING (64) | Subject Text for this eMail | | |
| | <i>value</i> | [..] | | | |
| input value 4 | <i>name</i> | Header | | | |
| | <i>type</i> | STRING (255) | Header text placed in front of mail text | | |
| | <i>value</i> | [..] | | | |
| input value 5 | <i>name</i> | Footer | | | |
| | <i>type</i> | STRING (255) | Footer text placed behind the mail text | | |
| | <i>value</i> | [..] | | | |
| <i>description</i> | Initializes the mail data for the new mail. The mail text is cleared and must be written using function SysNet_EmailWrite | | | | |

SysNet_EmailSend

| <i>name</i> | SysNet_EmailSend | | | <i>type</i> | <i>Function</i> |
|--------------------|--|---------------|--|-------------|-----------------|
| return value 1 | <i>type</i> | BOOL | Forwards the email to the mail send service of operating system. | | |
| | <i>value</i> | FALSE | Function skipped. An error occurred. | | |
| | | TRUE | Mail data successfully initialized | | |
| input value 1 | <i>name</i> | Mail | | | |
| | <i>type</i> | tSYSNET_EMAIL | Name of the Email, that must be sent | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| <i>description</i> | Forwards the email to the mail send service of operating system. The function return immediately. | | | | |
| | After transmission of the mail, the Confirm-Flag of the email is set TRUE , if transmission was successful, the Success-Flag of the mail is set TRUE | | | | |

SysNet_EmailSetFooter

| <i>name</i> | SysNet_EmailSetFooter | | | <i>type</i> | <i>Function</i> |
|--------------------|--|---------------|---|-------------|-----------------|
| return value 1 | <i>type</i> | BOOL | Changes the text footer for an existing mail | | |
| | <i>value</i> | FALSE | Function skipped. An error occurred. | | |
| | | TRUE | Footer changed successfully | | |
| input value 1 | <i>name</i> | eMail | | | |
| | <i>type</i> | tSYSNET_EMAIL | Name of the Email, that must be changed | | |
| | <i>value</i> | [..] | Check data type reference for available values. | | |
| input value 2 | <i>name</i> | Footer | | | |
| | <i>type</i> | STRING (255) | Text of the new footer | | |
| | <i>value</i> | [..] | | | |
| <i>description</i> | Changes the text footer for an existing mail | | | | |

SysNet_EmailSetHeader

| name | SysNet_EmailSetHeader | | | type | Function |
|----------------|--|---------------|---|------|----------|
| return value 1 | type | BOOL | Changes the text header for an existing mail | | |
| | value | FALSE | Function skipped. An error occurred. | | |
| | | TRUE | Header changed successfully | | |
| input value 1 | name | eMail | | | |
| | type | tSYSNET_EMAIL | Name of the Email, that must be changed | | |
| | value | [..] | Check data type reference for available values. | | |
| input value 2 | name | Header | | | |
| | type | STRING (255) | Text of the new header | | |
| | value | [..] | | | |
| description | Changes the text header for an existing mail | | | | |

SysNet_EmailSetRecipient

| name | SysNet_EmailSetRecipient | | | type | Function |
|----------------|--|---------------|---|------|----------|
| return value 1 | type | BOOL | Changes the recipient for an existing mail | | |
| | value | FALSE | Function skipped. An error occurred. | | |
| | | TRUE | recipient changed successfully | | |
| input value 1 | name | eMail | | | |
| | type | tSYSNET_EMAIL | Name of the Email, that must be changed | | |
| | value | [..] | Check data type reference for available values. | | |
| input value 2 | name | eEmailAddress | | | |
| | type | STRING (64) | email address of new recipient | | |
| | value | [..] | | | |
| description | Changes the recipient for an existing mail | | | | |

SysNet_EmailSetSubject

| name | SysNet_EmailSetSubject | | | type | Function |
|----------------|---|---------------|---|------|----------|
| return value 1 | type | BOOL | Changes the subject for an existing mail | | |
| | value | FALSE | Function skipped. An error occurred. | | |
| | | TRUE | subject changed successfully | | |
| input value 1 | name | eMail | | | |
| | type | tSYSNET_EMAIL | Name of the Email, that must be changed | | |
| | value | [..] | Check data type reference for available values. | | |
| input value 2 | name | Subject | | | |
| | type | STRING (64) | text of new subject | | |
| | value | [..] | | | |
| description | Changes the subject text for an existing mail | | | | |

SysNet_EmailTextClear

| name | SysNet_EmailTextClear | | | type | Function |
|----------------|---|---------------|--|------|----------|
| return value 1 | type | BOOL | Clears the complete mail text of an existing email | | |
| | value | FALSE | Function skipped. An error occurred. | | |
| | | TRUE | text changed successfully | | |
| input value 1 | name | eMail | | | |
| | type | tSYSNET_EMAIL | Name of the Email, that must be changed | | |
| | value | [..] | Check data type reference for available values. | | |
| description | Clears the complete mail text of an existing eMail, and may be used to create new text for a mail without creating the mail. All other settings for the eMail (recipient, subject, header and footer) will be unchanged | | | | |

SysNet_EmailWrite

| name | SysNet_EmailWrite | | | type | Function |
|----------------|--|---------------|--|------|----------|
| return value 1 | type | BOOL | Adds text to the actual eMail text | | |
| | value | FALSE | Function skipped. An error occurred | | |
| | | TRUE | Text added successfully | | |
| input value 1 | name | eMail | | | |
| | type | tSYSNET_EMAIL | Name of the Email, that must be changed | | |
| | value | [..] | Check data type reference for available values | | |
| input value 2 | name | MailText | | | |
| | type | STRING (255) | Add this text to the already existing mail text | | |
| | value | [..] | | | |
| input value 3 | name | CrLf | | | |
| | type | BOOL | Inserts Carriage Return and Line Feed | | |
| | value | FALSE | Nothing is added | | |
| | | TRUE | <Carriage Return> <Line Feed> is placed at the end of MailText | | |
| description | Adds the text to the actual eMail text. This function is used to fill the complete eMail text. If the function has added the complete text to the eMail, TRUE is returned. | | | | |

SysNet_HttpSetDir

| name | SysNet_HttpSetDir | | | type | Function |
|----------------|--|------------|---|------|----------|
| return value 1 | type | BOOL | Sets the active directory for the embedded web server | | |
| | value | FALSE | Function skipped. An error occurred. | | |
| | | TRUE | directory changed successfully | | |
| input value 1 | name | WebDirPath | | | |
| | type | String | Source path name for the web server | | |
| | value | [..] | | | |
| description | This function sets the active directory for the embedded web server. | | | | |

SysNet_HttpRegCgiFunction

| name | SysNet_HttpRegCgiFunction | | | type | Function |
|----------------|---|------------------|---|------|----------|
| return value 1 | type | BOOL | | | |
| | value | FALSE | Function skipped. An error occurred. | | |
| | | TRUE | Function registered successfully. | | |
| input value 1 | name | CgiFunction | | | |
| | type | UINT | Index of the CGI function | | |
| | value | [1.. 13] | Check table below for available values | | |
| input value 2 | name | FunctionPouUndex | | | |
| | type | UINT | index of CGI Script Controller Function, using CoDeSys INDEXOF() operator | | |
| | value | [..] | | | |
| description | This function registers the functions for XML script processing in order to support dynamic web sites | | | | |

The following indexes are used for registering CGI functions.

| <i>CGI Function</i> | <i>Index</i> | <i>Name of Function</i> |
|---------------------|--------------|-------------------------|
| | 1 | CGI Processor |
| | 2 | CgiGetSTRING |
| | 3 | CgiGetBOOL |
| | 4 | CgiGetUDINT |
| | 5 | CgiGetDINT |
| | 10 | CgiSetSTRING |
| | 11 | CgiSetBOOL |
| | 12 | CgiSetUDINT |
| | 13 | CgiSetDINT |

Check FBE tutorial 'How To Use WebVisu' in the download area for further instructions.

FBESYSMemory.lib

SysMem_EepromRd

| name | SysMem_EepromRd | | | type | Function |
|----------------|---|----------------------|---|------|----------|
| return value 1 | type | BOOL | Reads data from the EEPROM | | |
| | value | FALSE | Function skipped. An error occurred | | |
| | | TRUE | Data read successfully | | |
| input value 1 | name | EEPROMAddress | | | |
| | type | UINT | Address within EEPROM | | |
| | value | [..] | | | |
| input value 2 | name | MemoryAddress | | | |
| | type | UDINT | Destination Address for data read from EEPROM | | |
| | value | [..] | Check CoDeSys ADR() operator | | |
| input value 3 | name | ByteCount | | | |
| | type | UINT | Number of bytes to read from EEPROM | | |
| | value | [..] | | | |
| description | The function reads data from the EEPROM to the destination address. | | | | |

SysMem_EepromWr

| name | SysMem_EepromWr | | | type | Function |
|----------------|---|----------------------|--|------|----------|
| return value 1 | type | BOOL | Writes data to the EEPROM | | |
| | value | FALSE | Function skipped. An error occurred | | |
| | | TRUE | Data written successfully | | |
| input value 1 | name | EEPROMAddress | | | |
| | type | UINT | Address within EEPROM | | |
| | value | [..] | | | |
| input value 2 | name | MemoryAddress | | | |
| | type | UDINT | Address of first data to write to EEPROM | | |
| | value | [..] | Check CoDeSys ADR() operator | | |
| input value 3 | name | ByteCount | | | |
| | type | UINT | Number of bytes to write to EEPROM | | |
| | value | [..] | | | |
| description | The function writes data to the EEPROM address from the source address. | | | | |

SysMem_NVBlockEnable

| name | SysMem_NVBlockEnable | | | type | Function |
|----------------|--|---------------|---|------|----------|
| return value 1 | type | BOOL | | | |
| | value | FALSE | Function skipped. An error occurred | | |
| | | TRUE | NV Block successfully enabled | | |
| input value 1 | name | Enable | | | |
| | type | BOOL | Enables the NON VOLATILE (NV) memory block in "Merker/Memory" address area. | | |
| | value | TRUE | | | |
| | | FALSE | | | |
| description | Enables the NON-VOLATILE (NV) memory block in "Merker/Memory" address area. If enabled, the upper 1 kByte of "Merker/Memory" area is used as non-volatile memory that is never reinitialized. Also loading a new project does not reinitialize the NV memory. Valid address range : %MB15360 ... %MB16375 Please note: CODESYS does not check for data overlap. Take care to declare 16 or 32 bit data to even start address. | | | | |

SysMem_NVBlockDisable

| <i>name</i> | SysMem_NVBlockDisable | | | <i>type</i> | <i>Function</i> |
|-----------------------|------------------------------|---------------|--|-------------|-----------------|
| <i>return value 1</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | FALSE | Function skipped. An error occurred | | |
| | | TRUE | NV Block successfully disabled | | |
| <i>input value 1</i> | <i>name</i> | Enable | | | |
| | <i>type</i> | BOOL | Enables function to disable NV memory | | |
| | <i>value</i> | TRUE | | | |
| | <i>description</i> | | Disables the NON-VOLATILE (NV) memory block in "Merker" address memory area. | | |

SysMem_SaveRetainCmd

| <i>name</i> | SysMem_SaveRetainCmd | | | <i>type</i> | <i>Function</i> |
|-----------------------|-----------------------------|----------------|--|-------------|-----------------|
| <i>return value 1</i> | <i>type</i> | BOOL | | | |
| | <i>value</i> | FALSE | Function skipped. An error occurred | | |
| | | TRUE | Function successfully executed | | |
| <i>input value 1</i> | <i>name</i> | Size | | | |
| | <i>type</i> | INT | Enables function to disable NV memory | | |
| | <i>value</i> | [-1 ... 32767] | Size of data that must be saved manually. Use -1 to save complete retain data segment | | |
| | <i>description</i> | | Forces the system to save the retain data segment to non-volatile memory. Function is only needed on Core modules, if target hardware does not support power fail interrupt. Please note: function can take several 100 ms | | |

FBESysTime.lib

SysTime_GetTime

| <i>name</i> | SysTime_GetTime | | | <i>type</i> | <i>Function</i> |
|-----------------------|----------------------------------|------------------|--|--|-----------------|
| <i>return value 1</i> | <i>type</i> | TOD | | read time from RTC | |
| | <i>value</i> | [tod#hh:mm:ss] | | | |
| <i>input value 1</i> | <i>name</i> | Mode | | | |
| | <i>type</i> | UINT | | Reserved for future use: Set this parameter to 0 | |
| | <i>value</i> | 0 | | | |
| <i>description</i> | Function reads the time from RTC | | | | |

SysTime_GetDate

| <i>name</i> | SysTime_GetDate | | | <i>type</i> | <i>Function</i> |
|-----------------------|-----------------------------------|------------------|--|--|-----------------|
| <i>return value 1</i> | <i>type</i> | DATE | | read date from RTC | |
| | <i>value</i> | [d#yyyy-mm-dd] | | | |
| <i>input value 1</i> | <i>name</i> | Mode | | | |
| | <i>type</i> | UINT | | Reserved for future use: Set this parameter to 0 | |
| | <i>value</i> | 0 | | | |
| <i>description</i> | Function reads the date from RTC. | | | | |

SysTime_GetDateandTime

| <i>name</i> | SysTime_GetDateandTime | | | <i>type</i> | <i>Function</i> |
|-----------------------|---------------------------------------|----------------------------|--|--|-----------------|
| <i>return value 1</i> | <i>type</i> | DATE_AND_TIME | | read time and date from RTC | |
| | <i>value</i> | [dt#yyyy-mm-dd-hh:mm:ss] | | | |
| <i>input value 1</i> | <i>name</i> | Mode | | | |
| | <i>type</i> | UINT | | Reserved for future use: Set this parameter to 0 | |
| | <i>value</i> | 0 | | | |
| <i>description</i> | Function reads time and date from RTC | | | | |

SysTime_SetDate

| <i>name</i> | SysTime_SetDate | | | <i>type</i> | <i>Function</i> |
|-----------------------|---|------------------|-------------------------------------|-------------|-----------------|
| <i>return value 1</i> | <i>type</i> | BOOL | Set new date in RTC | | |
| | <i>value</i> | FALSE | An error occurred. Function skipped | | |
| | | TRUE | date successfully set | | |
| <i>input value 1</i> | <i>name</i> | NewDate | | | |
| | <i>type</i> | DATE | New date for RTC | | |
| | <i>value</i> | [d#yyyy-mm-dd] | | | |
| <i>description</i> | This function write a new date to the RTC | | | | |

SysTime_SetDateandTime

| name | SysTime_Get Date | | | type | Function |
|----------------|---|----------------------------|-------------------------------------|------|----------|
| return value 1 | type | BOOL | Set new dat and new time in RTC | | |
| | value | FALSE | An error occurred. Function skipped | | |
| | | TRUE | date and time successfully set | | |
| input value 1 | name | NewDateAndTime | | | |
| | type | DATE_AND_TIME | New date and time for RTC | | |
| | value | [dt#yyyy-mm-dd-hh:mm:ss] | | | |
| description | This function writes a new date and a new time to the RTC | | | | |

SysTime_SetTIME

| name | SysTime_Get Date | | | type | Function |
|----------------|--|------------------|-------------------------------------|------|----------|
| return value 1 | type | BOOL | Set new time in RTC | | |
| | value | FALSE | An error occurred. Function skipped | | |
| | | TRUE | time successfully set | | |
| input value 1 | name | NewTime | | | |
| | type | TOD | New time for RTC | | |
| | value | [tod#hh:mm:ss] | | | |
| description | This function writes a new time to the RTC | | | | |

FBESyslo.lib

The Library FBESyslo.lib is a Library extension for the CoDeSys PLC runtime system and supporting several utilities for IEC61131 applications running on systems from frenzel + berg elektronik. It is an internal library; all functions are included in the runtime system. With these functions a manipulation of the IO system is possible during the PLC loop.

Syslo_RdAllDigitalIn

| <i>name</i> | Syslo_RdAllDigitalIn | | | <i>type</i> | <i>Function</i> |
|-----------------------|--|-------------|--------------------------------------|-------------|-----------------|
| <i>return value 1</i> | <i>type</i> | BOOL | Read all digital input data | | |
| | <i>value</i> | FALSE | An error occurred. Function skipped | | |
| | | TRUE | All digital inputs read successfully | | |
| <i>input value 1</i> | <i>name</i> | Mode | | | |
| | <i>type</i> | UINT | Reserved for future use, set to 0 | | |
| | <i>value</i> | [0] | | | |
| <i>description</i> | This function reads all digital input data from hardware to PLC data. This function can be used to start an additional hardware input update within the PLC task or from interrupt level | | | | |

Syslo_WrAllDigitalOut

| <i>name</i> | Syslo_WrAllDigitalOut | | | <i>type</i> | <i>Function</i> |
|-----------------------|--|-------------|--|-------------|-----------------|
| <i>return value 1</i> | <i>type</i> | BOOL | Write all digital output data | | |
| | <i>value</i> | FALSE | An error occurred. Function skipped | | |
| | | TRUE | All digital outputs written successfully | | |
| <i>input value 1</i> | <i>name</i> | Mode | | | |
| | <i>type</i> | UINT | Reserved for future use, set to 0 | | |
| | <i>value</i> | [0] | | | |
| <i>description</i> | This function writes the complete digital output data of the PLC kernel to the hardware. This function can be used to force an additional hardware output update within the PLC task or from interrupt level | | | | |

Syslo_ResetDigitalOut

| <i>name</i> | Syslo_ResetDigitalOut | | | <i>type</i> | <i>Function</i> |
|-----------------------|---|---------------------|--|-------------|-----------------|
| <i>return value 1</i> | <i>type</i> | BOOL | Resets a single digital output channel. | | |
| | <i>value</i> | FALSE | Function skipped. An error occurred | | |
| | | TRUE | Output channel successfully reset | | |
| <i>input value 1</i> | <i>name</i> | OutputByteNr | | | |
| | <i>type</i> | UINT | Selects the output byte | | |
| | <i>value</i> | [0 .. 1] | | | |
| <i>input value 2</i> | <i>name</i> | OutputBitNr | | | |
| | <i>type</i> | UINT | Selects the bit of the corresponding output byte | | |
| | <i>value</i> | [0 .. 7] | | | |
| <i>description</i> | This function resets a single digital output channel. 1) The output is reset directly on the hardware without waiting for the IO update cycle at the end of the PLC loop 2) The corresponding memory location for the output data is also cleared | | | | |

Syslo_SetDigitalOut

| <i>name</i> | Syslo_SetDigitalOut | | | <i>type</i> | <i>Function</i> |
|-----------------------|---|---------------------|--|-------------|-----------------|
| <i>return value 1</i> | <i>type</i> | BOOL | Sets a single digital output channel. | | |
| | <i>value</i> | FALSE | Function skipped. An error occurred | | |
| | | TRUE | Output channel successfully set | | |
| <i>input value 1</i> | <i>name</i> | OutputByteNr | | | |
| | <i>type</i> | UINT | Selects the output byte | | |
| | <i>value</i> | [0 .. 1] | | | |
| <i>input value 2</i> | <i>name</i> | OutputBitNr | | | |
| | <i>type</i> | UINT | Selects the bit of the corresponding output byte | | |
| | <i>value</i> | [0 .. 7] | | | |
| <i>description</i> | This function sets a single digital output channel. 1) The output is set directly on the hardware without waiting for the IO update cycle at the end of the PLC loop 2) The corresponding memory location for the output data is also set | | | | |

Syslo_GetDigitalIn

| <i>name</i> | Syslo_GetDigitalIn | | | <i>type</i> | <i>Function</i> |
|-----------------------|--|---------------------|---|-------------|-----------------|
| <i>return value 1</i> | <i>type</i> | BOOL | reads the state of a digital input bit directly from hardware | | |
| | <i>value</i> | FALSE | Bit is low level | | |
| | | TRUE | Bit is high level | | |
| <i>input value 1</i> | <i>name</i> | OutputByteNr | | | |
| | <i>type</i> | UINT | Selects the input byte | | |
| | <i>value</i> | [0 .. 1] | | | |
| <i>input value 2</i> | <i>name</i> | OutputBitNr | | | |
| | <i>type</i> | UINT | Selects the bit of the corresponding input byte | | |
| | <i>value</i> | [0 .. 7] | | | |
| <i>description</i> | This function reads the state of a digital input bit directly from hardware. The input data is not updated | | | | |

Syslo_GetErrStatus

| <i>name</i> | Syslo_GetErrStatus | | | <i>type</i> | <i>Function</i> |
|-----------------------|---|-----------------|---|-------------|-----------------|
| <i>return value 1</i> | <i>type</i> | UINT | This function returns the status of output drivers. | | |
| | <i>value</i> | [0 ... 65535] | 0: no error detected >0: output driver disabled because of overload condition detected | | |
| <i>input value 1</i> | <i>name</i> | Mode | | | |
| | <i>type</i> | UINT | Reserved for future use, set to 0 | | |
| | <i>value</i> | [0] | | | |
| <i>description</i> | This function returns the status of output drivers. 0 no error >0 output driver disabled because of overload condition detected | | | | |

Syslo_SetWdtMode

| name | Syslo_SetWdtMode | | | type | Function |
|----------------|---|----------------|--|------|----------|
| return value 1 | type | BOOL | Modifies the mode for triggering the watchdog for digital output drivers | | |
| | value | FALSE | Function skipped | | |
| | | TRUE | Function successfully executed | | |
| input value 1 | name | SetMask | | | |
| | type | UINT | Sets the corresponding bits of WDT mode | | |
| | value | [0 .. 65535] | | | |
| input value 2 | name | ClearMask | | | |
| | type | UINT | Clears the corresponding bits of WDT mode | | |
| | value | [0 .. 65535] | | | |
| description | Modifies the mode for triggering the watchdog for digital output drivers: Bit 0 : Wdt is triggered on I/O update from PLC cycle Bit 1 : Wdt is triggered if CoDeSys application is topped on breakpoint Bit 8 : Wdt is triggered from operation system in any case | | | | |

Syslo_WrAllAnalogOut

| name | Syslo_WrAllAnalogOut | | | type | Function |
|----------------|--|-------|--|------|----------|
| return value 1 | type | BOOL | Write all digital output data | | |
| | value | FALSE | An error occurred. Function skipped | | |
| | | TRUE | All digital outputs written successfully | | |
| input value 1 | name | Mode | | | |
| | type | UINT | Reserved for future use, set to 0 | | |
| | value | [0] | | | |
| description | This functions writes the complete analog output data of the PLC kernel to the hardware. This function can be used to force an additional hardware output update within the PLC task or from interrupt level | | | | |

Syslo_WrAnalogOut

| name | Syslo_WrAnalogOut | | | type | Function |
|----------------|---|---------------------|-------------------------------------|------|----------|
| return value 1 | type | BOOL | Writes a single analog output | | |
| | value | FALSE | Function skipped. An error occurred | | |
| | | TRUE | Output channel successfully set | | |
| input value 1 | name | Channel | | | |
| | type | UINT | Analog Output Channel to write | | |
| | value | [0 .. 1] | | | |
| input value 2 | name | Value | | | |
| | type | INT | Value to write to this output | | |
| | value | [-32768 .. 32767] | | | |
| description | This functions writes a single analog output with new data to the hardware. | | | | |

FBESysJ1939.lib

| Functions | Description | |
|---------------|--|--|
| J1939_InitCan | Initializes the Basic-CAN-Interface | |
| J1939_IsRxMsg | Checks whether there are received J1939 frames | |
| J1939_RxMsg | Receives a J1939 message | |
| J1939_TxMsg | Transmits a J1939 message | |

Hardware Reference

hipecs PLC1010/1020/1030

| Available CAN Interfaces | | | |
|--------------------------|-----------------------------|-----------------------------|-----------------------------|
| CAN Interface Nr. | 0 | 1 | |
| CoDeSys Enumeration | CAN 0 | CAN 1 | |
| CAN Mode | CANopen / Basic CAN / J1939 | CANopen / Basic CAN / J1939 | CANopen / Basic CAN / J1939 |

hipecs CORE10 Modules

| Available CAN Interfaces | | | | |
|--------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| CAN Interface Nr. | 0 | 1 | 2 | 3 |
| CoDeSys Enumeration | CAN 0 | CAN 1 | CAN 2 | CAN 3 |
| CAN Mode | CANopen / Basic CAN / J1939 |

Data types defined for J1939 library

```
TYPE J1939 :  
STRUCT  
    Priority      : BYTE; (* Priority *)  
    PGN          : DWORD; (* Parameter Group Number *)  
    SAddr        : BYTE; (* Source Address *)  
    Data          : ARRAY [0..7] OF BYTE;  
    Len           : UINT;  
END_STRUCT  
END_TYPE
```

J1939_InitCan

| name | J1939_InitCAN | | | type | Function |
|---------------|---|----------------|--|------|----------|
| return value | type | BOOL | Returns the result state. | | |
| | value | TRUE | Init successful | | |
| | | FALSE | Function skipped. Init failed. | | |
| input value 1 | name | Node | | | |
| | type | SYSCAN_CANNODE | CAN Interface Number | | |
| | value | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| description | Initializes the Basic J1939 Interface. In order to J1939 add a CANopen master to the system configuration. Set baud rate within CANopen master. | | | | |

J1939_IsRxMsg

| name | J1939_IsRxMsg | | | type | Function |
|--------------|---------------|------|---------------------------|------|----------|
| return value | type | BOOL | Returns the result state. | | |

| | | | |
|----------------------|--|----------------|--|
| | <i>value</i> | TRUE | One or more messages available |
| | | FALSE | No message available |
| <i>input value 1</i> | <i>name</i> | Node | |
| | <i>type</i> | SYSCAN_CANNODE | CAN Interface Number |
| | <i>value</i> | CAN 0, CAN 1 | See hardware reference table for valid CAN interface |
| <i>description</i> | Functions check if there is one or more messages in the receiver buffer. | | |

J1939_RxMsg

| <i>name</i> | J1939_RxMsg | | | <i>type</i> | Function |
|----------------------|---|----------------|--|-------------|--------------------------------------|
| <i>return value</i> | <i>type</i> | J1939 | | | |
| | <i>value</i> | [..] | | | Returns data in J1939 message format |
| <i>input value 1</i> | <i>name</i> | Node | | | |
| | <i>type</i> | SYSCAN_CANNODE | CAN Interface Number | | |
| | <i>value</i> | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| <i>description</i> | Receives a message from the CAN Rx buffer | | | | |

J1939_TxMsg

| <i>name</i> | J1939_TxMsg | | | <i>type</i> | Function |
|-----------------------|--|----------------|--|-------------|---------------------------------------|
| <i>return value 1</i> | <i>type</i> | BOOL | | | Send the message to the CAN Tx buffer |
| | <i>value</i> | FALSE | | | Function skipped. An error occurred |
| | | TRUE | | | data valid and sent to buffer |
| <i>input value 1</i> | <i>name</i> | Node | | | |
| | <i>type</i> | SYSCAN_CANNODE | CAN Interface Number | | |
| | <i>value</i> | CAN 0, CAN 1 | See hardware reference table for valid CAN interface | | |
| <i>input value 2</i> | <i>name</i> | TxMsg | | | |
| | <i>type</i> | J1939 | Message in the J1939 format | | |
| | <i>value</i> | [...] | | | |
| <i>description</i> | This functions send a message in the J1939 data type format to the CAN transmit buffer | | | | |